



# INSTRUCTIONS

GEH-2004H

SUPERSEDES GEH-2004G

## MAGNE-BLAST CIRCUIT BREAKER

### Types

AM-13.8-150-3

AM-13.8-150A-3

AM-13.8-250-3

AM-13.8-250A-3


AM-13.8-500-3

AM-13.8-500A-3

AM-13.8-500B-3

AM-13.8-500AB-3

With MS-13 Mechanism



SWITCHGEAR DEPARTMENT

GENERAL  ELECTRIC

PHILADELPHIA, PA.

# CONTENTS

|  | <u>PAGE</u> |
|--|-------------|
| INTRODUCTION .....                             | 3           |
| RECEIVING, HANDLING AND STORAGE .....          | 3           |
| INSTALLATION .....                             | 3           |
| DESCRIPTION OF OPERATION .....                 | 3           |
| ADJUSTMENTS .....                              | 5           |
| MAINTENANCE .....                              | 11          |
| RENEWAL PARTS .....                            | 20          |
| PARTS RECOMMENDED FOR NORMAL MAINTENANCE ..... | 21          |

Cover (8028580)

# MAGNE-BLAST CIRCUIT BREAKER TYPE AM-13.8-3 WITH MS-13 MECHANISM

## INTRODUCTION

The magne-blast circuit breaker is the removable interrupting element for use in vertical-lift metal-clad switchgear, to provide reliable control and protection of power systems. Among the many advantages of metal-clad switchgear are added protection to equipment and personnel, compactness, simplified installation and reduced maintenance. In keeping with these features the magne-blast breakers are designed for interchangeability and maneuverability, together with reliability and low maintenance requirements.

The magne-blast circuit breaker operates on the principle that an arc can be

interrupted in air by sufficiently elongating and cooling it. This is accomplished by means of a strong magnetic field that lengthens the arc and forces it into intimate contact with cool dielectric material. A sturdy, reliable operating mechanism assures low maintenance and long life, and the use of Self-X insulation reduces fire hazards to a minimum.

The AM-13.8 magne-blast breaker is available in a number of current ratings. Refer to the breaker nameplate for the complete rating information of any particular breaker. The short circuit conditions to be imposed on the breaker must

not exceed its rating, nor should it be called upon to operate at voltages or currents greater than those given on the nameplate. Since this book is written to cover several ratings of breakers that are of the same general design, all instructions will be of a general character and all illustrations will be typical, unless otherwise specified.

**PROPER INSTALLATION AND MAINTENANCE ARE NECESSARY TO INSURE CONTINUED SATISFACTORY OPERATION OF THE BREAKER.** The following instructions will provide complete information for placing the magne-blast breaker in service and for maintaining satisfactory operation.

## RECEIVING, HANDLING AND STORAGE

### RECEIVING AND HANDLING

Each breaker is carefully inspected and packed by workmen experienced in the proper handling and packing of electrical equipment. Immediately upon receipt of the circuit breaker, an examination should be made for any damage sustained in transit. If injury or rough handling is evident, a damage claim should be filed immediately with the transportation company and the nearest General Electric Sales Office should be notified.

It is expected that due care will be exercised during the unpacking and installation of the breaker so that no damage will occur from careless or rough handling, or from exposure to moisture or dirt. Loose parts associated with the breaker are always

included in the same crate. Check all parts against the packing list to be sure that no parts have been overlooked.

### STORAGE

It is recommended that the breaker be put into service immediately in its permanent location. If this is not possible, the following precautions must be taken to insure the proper storage of the breaker:

1. The breaker should be carefully protected against condensation, preferably by storing it in a warm dry room, since water absorption has an adverse effect on the insulation parts. Circuit breakers for outdoor metal-clad switchgear should be stored in the equipment only when power is available and the heaters are in operation to prevent condensation.

2. The breaker should be stored in a clean location, free from corrosive gases or fumes; particular care should be taken to protect the equipment from moisture and cement dust, as this combination has a very corrosive effect on many parts.

3. Machined parts of the operating mechanism, etc., should be coated with a heavy oil or grease to prevent rusting.

If the breaker is stored for any length of time, it should be inspected periodically to see that rusting has not started and to insure good mechanical condition. Should the breaker be stored under unfavorable atmospheric conditions, steps should be taken to dry out the breaker before it is placed in service.

## INSTALLATION

1. Remove box barrier and make a visual inspection to ascertain that the breaker is in satisfactory condition. Check all bearing surfaces of the mechanism for lubrication. Refer to the section on LUBRICATION (page 12).

2. Operate breaker manually using the maintenance closing device provided with the breaker. During the closing operation check to insure that the mechanism and breaker does not stick or bind during the entire stroke, that it latches securely in the closed position, and that it trips freely when the manual trip plunger is operated. The breaker should not be operated electrically

until it has been operated manually to insure this freedom of action.

The following adjustments should be checked at this point: (page 7)

- a. Primary contact wipe.
- b. Primary contact gap.
- c. Prop clearance.

3. Attach test coupler to circuit breaker and operate electrically several times. The control voltage should be checked at the breaker as indicated under CONTROL POWER CHECK (page 10).

4. Remove test coupler, and replace box barrier.

5. If breaker has been stored for a long period of time, it is recommended that the insulation be checked with the standard 60 cycle high potential test -- see INSULATION TEST (page 12).

6. Lubricate the silver portion of the primary disconnect studs by rubbing a small amount of contact lubricant D50H47 to form a thin coating on the ball contact.

7. Refer to instruction book GEH-1802 for final instructions before inserting the breaker into the metal-clad unit.

## DESCRIPTION OF OPERATION

The magne-blast breaker is composed of two major parts, the breaker element and the operating mechanism. The breaker element comprises three similar pole units,

each pole unit consisting of main and arcing contacts, an interrupter, and an enclosing box barrier that segregates the interrupting units from each other to provide insulation

between phases as well as from each phase to ground. The primary connections to the associated metal-clad equipment are made through the primary disconnect studs.

*These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.*

*To the extent required the products described herein meet applicable ANSI, IEEE and NEMA standards; but no such assurance is given with respect to local codes and ordinances because they vary greatly.*

The MS-13 operating mechanism shown in Fig. 1 is of the solenoid type designed to give high speed closing and opening. The closing operation is controlled by the control device (7). The control device also permits trip-free operation (tripping the breaker at any time during the closing operation) and prevents solenoid pumping (reclosing) after a trip-free operation. For a-c closing operation, rectifiers mounted elsewhere in the metal-clad unit are used to supply the direct current on which the closing coil operates. The breaker can be opened electrically, by remote control, or manually, by means of the manual trip device (6). All secondary connections from the breaker to the metal-clad unit are made through the coupler (1).

The operating mechanism used on those breakers designed for MI-6 metal-clad equipment differs somewhat from those designed for M-26 equipment but its operation is principally the same. These breakers are identified by the "A" suffix in the breaker nomenclature.

This mechanism is controlled by a relay scheme mounted in the metal-clad unit and a cut-off switch located on the breaker instead of the control device. Two seven terminal secondary couplers also replace the one sixteen terminal coupler. The positive interlock between the breaker and metal-clad unit is replaced with a trip interlock that trips the mechanism before raising or lowering of the breaker can be accomplished. A fork-type lever can be furnished to operate an auxiliary switch mounted in the metal-clad unit.

A positive interlock and interlock switch are provided between the breaker and metal-clad unit to prevent the raising or lowering of the breaker in the unit while in the closed position and to prevent a closing operation when the breaker is not in either the fully raised or lowered position. A plunger type interlock can also be provided to prevent the closing of two adjacent breakers at the same time or to operate an additional auxiliary switch mounted in the metal-clad unit.

**CLOSING OPERATION**

The closing operation of the breaker is primarily controlled by the control device, Fig. 2, mounted on the operating mechanism. The closing sequence is initiated from a control switch mounted on the door of the metal-clad unit or at a remote operating station. Operation of the closing control switch energizes the pickup coil of the control device. As the control device closes, seal-in contacts shunt the closing control switch to allow the opening of the closing control switch contacts without affecting the overall closing operation. This type of arrangement assures complete closing of the breaker with only momentary contact of the closing control switch.

Operation of the control device energizes the breaker closing coil by closing the main control device contacts (5 and 6), Fig. 2. Once the control device contacts

- 1. Secondary Coupler
- 2. Auxiliary Switch
- 3. Position Indicator
- 4. Opening Spring Unit
- 5. Operation Counter
- 6. Manual Trip
- 7. Control Device
- 8. Control Device Plunger Guide
- 9. Closing Solenoid





Fig. 1 MS-13 Operating Mechanism



- 1. Shunting and Anti-pump Switch
- 2. Seal-in Switch
- 3. Operating Coil
- 4. Crank
- 5. Stationary Contact Assembly
- 6. Movable Contact Assembly
- 7. Arm
- 8. Arc Chute
- 9. Trip Lever
- 10. Plunger Guide

Fig. 2 Control Device

are picked up, they are electrically held in the closed position until the breaker closing operation is completed. Energizing the breaker closing coil raises the armature (6), Fig. 3, which in turn lifts the closing roller (4) through plunger (14). This motion is transmitted through the mechanism linkage and rotates the main crank (1), closing the breaker contacts. As the armature reaches the end of its travel, the prop (12) rotates beneath the pin (11) latching the breaker in the closed position. During the closing operation, the opening springs (9 and 10) are compressed in readiness for an opening operation.

Air trapped above the armature acts as a dash pot to absorb the energy of the mechanism as it approaches the end of its stroke.

When the armature is near the end of its stroke, the control device plunger (5), Fig. 22, mechanically trips the main control device contacts, de-energizing the closing coil and allowing the armature to return by gravity to its original position. The control device plunger also mechanically trips the seal-in switch, de-energizing the control device coil if the closing control switch is not closed. If the closing control switch is

FIG. 1 (8024603) FIG. 2 (8024603)



normal position, ready for closing.


As the breaker opens, the main contacts part first, shunting the current through the arcing contacts. An arc forms as the arcing contacts part (see Fig. 4). As the movable arcing contact (27) is withdrawn through the slot in the arc runner, the upper end of the arc is transferred to the upper arc runner (4). To assist the interruption at this point, a stream of air is emitted from the booster tube (28) and forces the arc onto the lower arc runner (10). Establishment of the arc on the runners automatically inserts the first blow-out coil into the circuit, introducing a magnetic field between the pole pieces which tends to draw the arc away from the arcing contacts. The 150 and 250 MVA interrupter contains three upper magnetic blowout coils and one lower blowout coil each individually connected in series with its respective section of arc runner. The 500 MVA interrupter contains three upper blowout coils and three lower blowout coils each individually connected in series with its respective section of arc runner. As the arc is forced outward along the diverging arc runners, the magnetic field is progressively increased with the addition of each coil in the circuit.

At the same time, the arc is being forced into the arc chute (8) which is composed of a series of gradually interleaving insulating fins. These fins, which project alternately from the two opposite inner surfaces of the chute, elongate the arc into a gradually deepening serpentine path, so that the electrical resistance in the path of the arc is rapidly increased and the heat from the arc is absorbed. The increased resistance reduces both the magnitude and the phase angle of the current, and at an early current zero the arc path is so long and the gases produced by the arc so cooled that the arc cannot re-establish itself, and interruption occurs.

Manual tripping follows the same procedure except that instead of energizing the trip circuit, the manual trip (6), Fig. 1, is used.

#### TRIP-FREE OPERATION

If the trip coil circuit is energized while the breaker is closing, the trip plunger will force the trip latch (2) Fig. 3, away from the trip roller (3) causing the mechanism linkage to collapse and the breaker to re-open. The closing armature (6) completes its closing stroke, but the closing coil is de-energized at the end of the stroke, and the armature is returned to its original position by gravity.



- |                   |                           |                         |
|-------------------|---------------------------|-------------------------|
| 1. Main Crank     | 6. Closing Armature       | 11. Closing Pin         |
| 2. Trip Latch     | 7. Armature Guide Bolts   | 12. Prop                |
| 3. Trip Roller    | 8. Spring Retainer        | 13. Closing Coil        |
| 4. Closing Roller | 9. Opening Spring, Inner  | 14. Closing Plunger Rod |
| 5. Piston Ring    | 10. Opening Spring, Outer |                         |

Fig. 3 Cross Section of MS-13 Operating Mechanism in the Open Position

held in the closed position through and after the breaker closing operation, the control device linkage will remain picked up and be unable to reset to prepare for another breaker closing operation. This arrangement insures that "pumping" of the breaker will not occur during a trip-free operation.

The operating sequence for those breakers designed for MI-6 metal-clad equipment is similar to that described above except that a relay mounted elsewhere in the metal-clad unit replaces the control device. Also, a cut-off switch (Fig. 11) is used to replace the mechanical trip arrangement of the control device. The cut-off switch energizes an auxiliary relay to de-energize the main relay.

#### OPENING OPERATION

An electrical opening operation is initiated by energizing the trip coil. This is accomplished either by actuating the opening control switch on the metal-clad unit or by a combination of relays and current devices used to detect a fault on the load side of the breaker. By energizing the trip coil, the trip plunger rotates the trip latch (2), Fig. 3, causing the operating mechanism linkage to collapse. The energy stored in the opening springs (9 and 10) is thus released, opening the breaker. During this operation, the trip coil circuit is de-energized, and upon completion of the opening operation, the operating mechanism is returned to its

## ADJUSTMENTS

**DO NOT WORK ON EITHER THE BREAKER OR THE MECHANISM WHILE IN THE CLOSED POSITION UNLESS THE PROP AND TRIP LATCH HAVE BEEN SECURELY WIRED OR BLOCKED TO PREVENT ACCIDENTAL TRIPPING.**

A maintenance operating device is provided for operation of the breaker during these adjustment checks. Mount the device

as shown in Fig. 5, and turn the release valve (4) firmly to the right. To close the breaker, operate the handle (2) with a pumping motion. By turning the release valve (4) to the left, the closing armature will return to its normal position. Electrical operation must not be attempted until the breaker has been operated manually through its complete stroke several times and final installation inspection has been completed.

All adjustments should be checked during periodic inspections and whenever it becomes necessary to repair or replace parts that have become worn or defective while in service. The following adjustments are listed in the order in which they are to be checked. First, however, remove the breaker from the metal-clad unit and remove the box barrier.





Fig. 4 (2540732)


- |                           |                               |                                  |
|---------------------------|-------------------------------|----------------------------------|
| 1. Box Barrier Catch      | 11. Pole Pieces               | 21. Stationary Primary Contact   |
| 2. Box Barrier            | 12. Front Bushing             | 22. Movable Primary Contact      |
| 3. Arc Chute              | 13. Rear Bushing              | 23. Movable Contact Arm Assembly |
| 4. Arc Runner, Upper      | 14. Upper Horizontal Barrier  | 24. Cup Bearing                  |
| 5. Blow Out Coil, Upper   | 15. Main Operating Crank      | 25. Booster Tube and Piston      |
| 6. Blow Out Core, Upper   | 16. Arc Chute Support         | 26. Front Vertical Barrier       |
| 7. Movable Arcing Contact | 17. Spring Retainer           | 27. Check Nut                    |
| 8. Arc Runner, Lower      | 18. Lower Horizontal Barrier  | 28. Connection Bar               |
| 9. Blow Out Coil, Lower   | 19. Operating Rod             | 29. Booster Cylinder             |
| 10. Blow Out Core, Lower  | 20. Stationary Arcing Contact | 30. Side Barrier                 |

Fig. 4 Cross Section of Breaker Pole Unit



1. Closing Armature Cover
2. Handle
3. Maintenance Operating Device
4. Release Valve

Fig. 5 Method of Mounting Maintenance Operating Device



Primary Contact Wipe

1. Stationary Primary Contacts
2. Movable Primary Contacts

Arcing Contact Wipe

3. Buffer Block
4. Stationary Arcing Contacts
5. Movable Arcing Contacts
6. Upper Arc Runner

Fig. 6 Contact Adjustments

PRIMARY CONTACT WIPE

When the breaker is closed, as shown in Fig. 6, the stationary primary contacts (1) should rise  $5/16'' + 0-1/16''$ . To obtain this adjustment, open the breaker and, referring to Fig. 7, loosen the check nut (4) and turn the adjusting nut (3). Screwing up on the adjusting nut will decrease the primary contact wipe, down will increase it. Tighten the check nut, close the breaker and recheck the wipe. With the primary contact wipe correctly adjusted, the clearance between the contact arm (7) and the buffer block should be  $1/16''$  or greater (as shown in Fig. 6) when the breaker is fully closed.

ARCING CONTACT WIPE

Refer to Fig. 6. Close the breaker until the arcing contacts just touch. This can be determined with the use of a circuit continuity tester such as a light indicator or bell set. In this position, the gap between the stationary primary contacts (1) and the movable primary contact (2) should be  $5/16''$  or greater. This setting has been made in the factory and no adjustment is provided. A wipe of less than  $5/16''$  is usually an indication that the arcing contacts need to be replaced. When making this check also see that the movable arcing contact (5) passes through the slot in the upper arc runner (6) without touching.

PRIMARY CONTACT GAP

Refer to Fig. 7. With the breaker closed, press the manual trip button allowing the breaker to trip open normally. Do not force the contacts open wider by hand. The gap between the stationary primary contacts (5) and the movable primary contact (6) should be  $5-1/4'' + 5/16'' - 1/8''$ . To change this gap, loosen the check nut (25), Fig. 8, and turn the adjusting nut (26) on stud (9). Screwing the adjusting nut down will decrease the primary contact gap. Tighten the check nut and re-measure the contact gap (close and trip the breaker before checking the measurement).



1. Operating Rod
2. Operating Rod Pin
3. Adjusting Nut
4. Check Nut
5. Stationary Primary Contacts
6. Movable Primary Contacts
7. Contact Arm

Fig. 7 Adjustable Coupling for Making Primary Contact Wipe Adjustment


TRIP LATCH WIPE

Refer to Fig. 8. The wipe of the trip latch (4) on the trip roller (6) should be from  $3/16''$  to  $1/4''$ . This can be measured by putting a film of grease on the latch (4), closing the breaker part way, and tripping. The mechanism has the proper trip latch wipe when the latch rests against the stop pin (5). No adjustment is provided and a visual inspection is usually all that is required. If this setting is not correct, look for insufficient travel of the trip shaft (3).

**WHEN WORKING ON THE MECHANISM IN THE CLOSED POSITION, KEEP FINGERS CLEAR OF THE LINKAGE, AS ACCIDENTAL TRIPPING CAN CAUSE SEVERE INJURY.**

PROP CLEARANCE

Refer to Fig. 8. With the breaker closed as far as possible with the maintenance device, the clearance between the closing pin (10) and the prop (15) should be  $1/32''$  to  $3/32''$ . Measure the prop clearance with a feeler gage to determine whether or not an adjustment should be made, and if so, exactly how much adjustment will be required. To make the adjustment, it will first be necessary to open the breaker and remove the maintenance operating device. Remove the stop nuts (22 and 24) being careful not to drop the armature (21). Lower the armature from the mechanism and remove the two set screws (19). Remove the closing plunger (17) from the armature and add or subtract the necessary thickness of shims (20) to give the required



- |                       |                            |                          |
|-----------------------|----------------------------|--------------------------|
| 1. Main Oper. Shaft   | 11. Opening Spring Housing | 18. Piston Ring          |
| 2. Main Crank         | 12. Opening Spring, Inner  | 19. Set Screw            |
| 3. Trip Shaft         | 13. Opening Spring, Outer  | 20. Shims                |
| 4. Trip Latch         | 14. Closing Roller         | 21. Closing Armature     |
| 5. Trip Latch Stop    | 15. Prop                   | 22. Stop Nuts            |
| 6. Trip Roller        | 16. Closing Coil           | 23. Armature Guide Bolts |
| 7. Position Indicator | 17. Closing Plunger        | 24. Stop Nuts            |
| 8. Clevis             |                            | 25. Check Nut            |
| 9. Adjustable Stud    |                            | 26. Adjusting Nut        |
| 10. Closing Pin       |                            |                          |

Fig. 8 Cross Section of MS-13 Mechanism

adjustment, then replace the closing plunger, screwing it down against the shims. Using a small drill, spot the closing plunger through the set screw hole. Replace the set screws. To remount the armature on the breaker, compress the piston ring (18). After reassembly, remount the maintenance closing device and check the adjustment.

**CLOSING PLUNGER CLEARANCE**

Refer to Fig. 8. With the breaker in the open position, the clearance between the closing plunger (17) and the closing roller (14) should be 1/16" to 3/16". To obtain this clearance, the nuts (22) on the two armature guide bolts (23) may be raised or lowered. Both nuts should be moved the same amount. After making an adjustment, close and open the breaker and recheck the plunger clearance. Repeat the adjustment if necessary.

**INTERLOCK SWITCH WIPE**

Referring to Fig. 9, rotate the interlock shaft (1) manually clockwise to release the interlock switch arm (2). The point at which the contacts make can be determined with a circuit continuity tester such as a light indicator or bell set. To obtain adjustment on the interlock switch (4), bend the interlock switch arm (2). The roller and crank on the interlock switch (4) should have 1/32" to 1/16" overtravel after final adjustment.

**CONTROL DEVICE ADJUSTMENT**

Referring to Fig. 10, measure the overtravel of the two auxiliary switch plungers. Manually operate the control device by pressing the operating arm (5) the full extent of travel to the rear. With the device in this position further depress the plunger (4) on the top auxiliary switch



Fig. 8 (2580688)

- |                         |                              |
|-------------------------|------------------------------|
| 1. Interlock Shaft      | 5. Latch Checking Switch Arm |
| 2. Interlock Switch Arm | 6. Roller                    |
| 3. Roller               | 7. Latch Checking Switch     |
| 4. Interlock Switch     | 8. Trip Shaft                |

Fig. 9 Interlock Switch and Latch Checking Switch




Fig. 9 (8024689)

- |                          |                  |
|--------------------------|------------------|
| 1. Back Auxiliary Switch | 5. Operating Arm |
| 2. Mounting Screw        | 6. Trip Lever    |
| 3. Top Auxiliary Switch  | 7. Plunger Guide |
| 4. Plunger               |                  |


Fig. 10 Control Device

(3). The gap between the plunger and operating arm should be 1/32" or greater. To increase the overtravel, loosen the screws (2) and move the switch toward the rear of the mounting plate. Tighten the screws and recheck the adjustment.

In a similar manner, check the overtravel on the back auxiliary switch (1).

**BEFORE MANUALLY OPERATING THE CONTROL DEVICE, MAKE CERTAIN THAT ALL CONTROL POWER TO THE BREAKER HAS BEEN DISCONNECTED. MANUAL OPERATION OF THE CONTROL DEVICE WITH CONTROL POWER CONNECTED WILL ENERGIZE THE CLOSING COIL AND PRODUCE A CLOSING OPERATION.**

Fig. 10 (8024689)



- |                     |              |
|---------------------|--------------|
| 1. Cut-off Switch   | 4. Washers   |
| 2. Switch Roller    | 5. Lever Arm |
| 3. Adjustment Screw |              |

Fig. 11 Cut-off Switch Adjustments

**CUT-OFF SWITCH ADJUSTMENTS**  
(13.8-150A-3, 250A-3, 500A-3)

Refer to Fig. 11. The operating arm, (5) is set at the factory and will require no adjustment. With the breaker in the open position, depress the arm of the cut-off switch (1). There should be 1/32" to 1/16" clearance between the depressed roller of the switch and the striker (3). Washers (4) should be added or removed if necessary to correct adjustment.

**AUXILIARY DEVICES**

Latch Checking Switch Wipe


Referring to Fig. 9, rotate the trip shaft (8) manually clockwise to release the latch checking switch arm (5). The point at which the contacts make can be determined with a circuit continuity tester such as a light indicator or bell set. To obtain adjustment on the latch checking switch (7), bend the latch checking switch arm (5). The roller and crank on the latch checking switch (7) should have 1/32" to 1/16" over-travel after final adjustment.

Impact Trip, Current Trip, Capacitor Trip, and Undervoltage Trip Devices

Fig. 12 shows the necessary settings that are to be checked when these devices are furnished. The amount of wipe between the trip roller (16) and the trip latch (15) should be 3/32" to 5/32". This can be altered by changing the number of shims under the block against which the trip plate (14) stops.

In order to trip properly, the clearance between the trip bolt (11) and the trip plate (9) should be 1/32" to 1/16". This can be altered by releasing the check nut and screwing the trip bolt (11) in or out of the reset arm (8).

When an undervoltage device is furnished, check the clearance between the trip hammer (19) and the trip plate (14), with the undervoltage coil energized. This clearance should be 1/32" to 1/16" and can be altered by removing the connecting



- |                          |                       |                              |
|--------------------------|-----------------------|------------------------------|
| 1. Front Disconnect Stud | 9. Trip Plate         | 17. Trip Armature            |
| 2. Interlock Bolt        | 10. Spring            | 18. Trip Lever               |
| 3. Washers               | 11. Trip Bolt         | 19. Undervoltage Trip Hammer |
| 4. Connecting Rod        | 12. Clevis            | 20. Adjusting Rod            |
| 5. Reset Plate           | 13. Elevating Bar     | 21. Manual Trip Button       |
| 6. Reset Roller          | 14. Impact Trip Plate | 22. Trip Setting Plate       |
| 7. Main Operating Shaft  | 15. Trip Latch        | 23. Undervoltage Device      |
| 8. Reset Arm             | 16. Trip Roller       |                              |

Fig. 12 Adjustments On Current Trip Device And Undervoltage Trip Device, Shown With The Breaker In The Closed Position

pin at either end of the adjusting rod assembly (20), and turning the clevis at that end.

After checking all the mechanical adjustments as outlined above, operate the devices manually to make certain that they trip and reset properly.

Plunger Interlock

Refer to Fig. 12. With the breaker in the open position, the vertical distance "A" from the top of the interlock bolt (2) to the bottom of the elevating bar (13) should be 10-7/32" ± 1/16". To change this adjustment, add or remove washers (3).

**AUXILIARY SWITCH LINKAGE**  
(FURNISHED SPECIAL ON 13.8-150A, 250A, 500A)

Refer to Fig. 13. With the breaker in the open position, the distance from the centerline of the front operating pin (3) to the center of the switch operating pin (4) should be 12-1/4" as shown. To change this setting, loosen the locking nut (6), remove the pin (4) and turn the clevis (5). Reassemble and check adjustments.

Auxiliary Switch

The auxiliary switch is mounted on the right side of the operating mechanism (2),




Fig. 13 Auxiliary Switch Linkage Shown with the Breaker in the Open Position

Fig. 1. The shaft of the position indicator operates the auxiliary switch shaft which opens and closes the "a" and "b" contacts. (The "a" contacts are open when the breaker is open and the "b" contacts are open when the breaker is closed). The "a" contacts should close when the breaker primary contact gap is a minimum of 1". The "b" contacts need only to be checked to see that they are open when the breaker is closed.

Fig. 11 (8021970)

Fig. 12 (6340336)

Fig. 13 (2648153)

**FINAL INSPECTION AND TEST**

1. For ease in reviewing the adjustments, the following are recapitulated:
  - a. Primary contact wipe: 5/16" + 0 - 1/16".
  - b. Arcing contact wipe: 5/16" or greater (gap at primary contacts).
  - c. Primary contact gap: 5-1/4" + 5/16" - 1/8".
  - d. Trip latch wipe: 3/16" to 1/4" with trip latch resting against stop pin.
  - e. Prop clearance: 1/16" ± 1/32".
  - f. Closing plunger clearance: 1/16" to 3/16".
  - g. Interlock switch wipe: 1/32" to 1/16" overtravel.
  - h. Control device switch overtravel: 1/32" min.
  - i. Cut-off switch overtravel: 1/32" - 1/16" (150A, 250A, 500A).
  - j. Latch checking switch wipe: 1/32" to 1/16" overtravel.
  - k. Impact trip roller wipe: 1/8" ± 1/32".
  - l. Impact trip bolt clearance: 3/64" ± 1/64".
  - m. Undervoltage trip hammer clearance: 3/64" ± 1/64".
  - n. Plunger interlock: 10-7/32" ± 1/16".
  - o. Auxiliary switch linkage: (150A, 250A, 500A) 12-1/4".
  - p. Auxiliary switch "a" contacts close when breaker primary contact gap is 1" or greater.
2. Check all nuts, washers, bolts, cotter pins, and terminal connections for tightness.
3. Inspect all wiring to make sure that no damage has resulted during installation, and test for possible grounds or short circuits.
4. See that all bearing surfaces of the mechanism have been lubricated. Refer to the section on LUBRICATION.
5. Operate the breaker slowly with the maintenance closing device and note that there is no excessive binding or friction and that the breaker can be moved to the fully opened and fully closed positions.
6. See that any place where the surface of the paint has been damaged is repainted immediately.

**AUXILIARY DEVICES**

On breakers that are equipped with auxiliary devices such as a current trip, undervoltage trip or capacitor trip, the device should be checked for proper electrical operation. The current trip device should trip the breaker at 3 amperes. The

undervoltage trip device should trip the breaker when the control voltage drops below 30 to 60% of rated voltage, and it should pick up at 80% of the control voltage or less. An adjustment plate is provided on the front of the undervoltage trip device as an aid in obtaining the desired setting.

**NOTE:** When checking the pick-up value of the undervoltage device, apply a voltage equal to 80% of normal control voltage to the undervoltage device coil. The device should pick up at this value. Do not increase the voltage gradually on this coil as it will overheat the coil, producing a false reading, and may damage the coil if excessive overheating occurs.

The capacitor trip should be capable of tripping the breaker as late as 25 seconds after the control voltage is removed. If the auxiliary devices do not perform in accordance with these specifications, a careful examination should be made for defective parts.

**OPENING AND CLOSING SPEED**

The closing speed of the arcing contact should be 7 to 10 feet per second for the 150, 250 MVA breakers and 9 to 13 feet per second for the 500 MVA breakers with rated closed circuit voltage at the closing coil terminals. These speeds represent the average speed of the movable arcing contact from a point 1" before the tip is tangent to the lower surface of the upper arc runner to the tangent position.

The opening speed of the arcing contact should be 10 to 15 feet per second at rated control voltage. This speed represents the average speed over 3" from the point when the tip on the movable arcing contact is tangent to the lower surface of the upper runner.

**CONTROL POWER CHECK**

After the breaker has been closed and opened slowly several times with the maintenance closing device, and the mechanism adjustments checked as described above, the operating voltages should be checked at the closing coil and trip coil terminals. For electrical operation of the breaker, the control power may be either an alternating or direct current source. The operating ranges for the closing and tripping voltages are given on the breaker nameplate. Ordinarily, standard ranges apply which are as follows:

| NOMINAL VOLTAGE | CLOSING RANGE | TRIPPING RANGE |
|-----------------|---------------|----------------|
| 125 v d-c       | 90-130 v d-c  | 70-140 v d-c   |
| 250 v d-c       | 180-260 v d-c | 140-280 v d-c  |
| 230 v a-c       | 190-250 v a-c | 190-250 v a-c  |

**NOTE:** When repetitive operation is required from a direct current source, the closed circuit voltage at the closing coil should not exceed 115v d-c and 230v d-c at the nominal voltages of 125v d-c and 250v d-c respectively.

To check the d-c voltage at the closing coil terminals, proceed as follows:

1. Mechanism with a control device, Fig. 10. Close the breaker by manually

operating the control device. Hold the contacts in the closed position and read the d-c voltage at the closing coil terminals. To de-energize the circuit, release the control device.

2. Mechanism with cut-off switch, Fig. 11. Close the breaker by manually operating the control relay located in the metal-clad unit. Hold the relay closed and read the d-c voltage at the closing coil terminals. Release the closing relay to de-energize the circuit.

If the closed circuit voltage at the terminals of the closing coil does not fall in the specified range, proceed as follows:

**FOR D-C OPERATION**

D-c control power source. Check voltage at the source of power and line drop between the power source and breaker.

**FOR A-C OPERATION**

1. When copper-oxide rectifiers are used they are mounted in the metal-clad unit. A tapped 1-1/2 ohms resistor is provided in each rectifier circuit to control the d-c voltage. The resistor setting should be adjusted so that the closed circuit voltage at the breaker closing coil terminals is 110 to 120 volts d-c. Where repetitive operation is required, the voltage should be set at 105 to 115 volts d-c.

| * A-c Volts<br>(Closed Circuit) | Resistor Setting for<br>Each Resistor |        |
|---------------------------------|---------------------------------------|--------|
|                                 | Summer                                | Winter |
| 190-196                         | 1/4                                   | 0      |
| 194-206                         | 1/2                                   | 0      |
| 204-216                         | 1/2                                   | 1/4    |
| 214-226                         | 3/4                                   | 1/4    |
| 224-236                         | 1                                     | 1/2    |
| 234-246                         | 1-1/4                                 | 3/4    |
| 244-250                         | 1-1/4                                 | 1      |

\* A-c volts as measured across the rectifier and a-c series resistor.

The preceding tabulation is included as a guide for adjusting the resistors for the particular combination of ambient temperature and a-c supply voltage. Summer settings are used where ambient temperatures are normally above freezing (32° F). It is necessary to use winter settings where the ambient temperature may drop to 20° F or less at any time. For a more detailed explanation of copper-oxide rectifiers for circuit breaker application, refer to instruction book GEI-11306.

2. When a germanium (color-black, flanged base) or a silicon (color-blue, hex base) rectifier bridge assembly is used, it is mounted in the metal-clad unit. These rectifiers are hermetically sealed units. They have been tested and the associated resistor properly set at the factory. Unlike copper-oxide rectifiers the output of the germanium or silicon unit is affected very little by ambient temperature changes and it should not be necessary to disturb the factory setting. (See Rectifier Reference Chart.)



DO NOT MAINTAIN VOLTAGE ON THE CLOSING COIL ANY LONGER THAN THE TIME REQUIRED TO CLOSE THE BREAKER. (20 Cycles maximum at normal voltage). Both the coils and the germanium and silicon rectifiers are designed for intermittent operation and may be damaged by prolonged current flow.

When two or more breakers, operating from the same control power source, are required to close simultaneously, the closed circuit voltage at the closing coil of each breaker must fall within the specified limits.

Electrical closing or opening is accomplished by merely energizing the closing or trip coil circuit. Control switches are provided for this purpose on the metal-clad unit. It is also possible to trip the breaker manually by pressing the manual trip button (6), Fig. 1.

Before the breaker is finally raised into position in the metal-clad unit, rub a small amount of G. E. Contact Lubricant D50H47 on the silvered portion of the breaker studs to form a thin coating for contacting purposes.

NOTE: This breaker mechanism combination is designed only for electrical closing when in use. NEVER ATTEMPT MANUAL CLOSING WITH THE BREAKER IN SERVICE, for under such conditions, sufficient closing force and speed cannot be applied.

| RECTIFIER REFERENCE CHART |                     |                            |         |               |
|---------------------------|---------------------|----------------------------|---------|---------------|
| Closing Coil              |                     | Rectifier Resistor Setting |         |               |
| Dwg. No.                  | Amps.               | Germanium                  | Silicon | Resistor Taps |
| 6375521G-6                | 58.0<br>to<br>62.0  | 1.50                       | 1.25    |               |
| 6375521G-2                | 95.0<br>to<br>115.0 | 1.0 (ea. bridge)           | 0.75    |               |
| 6375522G-2                | 180.0               | .75 (ea. bridge)           | 0.625   |               |

Fig. 13A

## GENERAL MAINTENANCE

### ARC CHUTES

It is not necessary to inspect the arc chutes unless there is evidence of damage or if the arc chutes are removed for any reason. When inspecting an arc chute, it should be disassembled and the following points noted:

- Scale formed over the surface of the arc chute must not be removed, but loose particles collected in the chute should be blown out.
- Cracks which have formed in the fins of the arc chute are to be expected in ceramic materials of this type when subjected to the severe heat of an arc. These cracks do not interfere with the operation of the device in any way and should be disregarded. Small broken corners on the exhaust end of the chute will not interfere with its performance and can also be disregarded.
- If the arc chute has suffered any mechanical injury due to dropping or accidental striking, resulting in the actual breaking off of fins, replacement of the chute will be necessary.
- The plastisol flexible covering for the pole pieces (3 & 4) Fig. 16 and the upper mounting support (13) Fig. 16 should be inspected for breaks in the insulation. If there are holes or breaks in the insulation they should be repaired or the part replaced.

### BREAKER CONTACTS

By removing the box barrier the movable and stationary primary contacts and the movable arcing contacts can be inspected. The stationary arcing contacts can be inspected only after removing the

arc chute assembly, as explained under REPAIR AND REPLACEMENT. If the contacts are burned or pitted, they should be made smooth with a fine file.

After completing inspection of the contacts, check the contact adjustments as specified under INSTALLATION, ADJUSTMENTS.

### MECHANISM

A careful inspection should be made to check for loose nuts or bolts and broken retaining rings. All cam, roller, and latch surfaces should be inspected for any evidence of damage or excessive wear. Lubricate the mechanism as outlined below, then, using the maintenance operating device, open and close the breaker several times to make certain that the mechanism operates freely throughout its entire stroke. Check the mechanism adjustments as specified under INSTALLATION, ADJUSTMENTS. Check all terminal connections.

### BUSHINGS AND INSULATION

The surface of the bushings should be kept clean and unmarred to prevent moisture absorption. If the insulation surface should become damaged, it should be sanded and cleaned, and should be refinished with either clear varnish (GE-1170) or clear Glyptal\* resin (GE-1202). Allow to dry smooth and hard.

All other insulation parts on the breaker should be kept clean and dry. Smoke or dust collected between inspection periods should be wiped off, and if dampness is apparent, heaters should be installed to insure dryness.

**INSULATION TEST**

When insulation has been repaired or replaced, or when breaker has been stored under adverse conditions, it is recommended that the insulation be checked before the breaker is placed in service. A standard 60 cycle high potential test at 27,000 volts RMS will normally indicate whether the breaker is satisfactory for service. With the breaker contacts in the fully opened position, apply the high potential to each terminal of the breaker individually for one minute with all other terminals and the breaker frame grounded. After high potential tests are made on organic insulating materials, these materials should be inspected for visible leakage current paths, and necessary action must be taken to replace insulation that may have been affected by moisture absorption.

**LUBRICATION**

In order to maintain reliable operation, it is important that all circuit breakers be properly lubricated at all times. During assembly at the factory, all bearing surfaces, machined surfaces, and all other parts of the breaker and mechanism subject to wear have been properly lubricated using the finest grade of lubricants available. However, even the finest oils and greases have a tendency to oxidize with age, as evidenced by hardening and darkening in color. Elimination of the hardened lubricant is essential for the proper operation of circuit breakers. Also frequent operation of the breaker causes the lubricant to be forced out from between the bearing surfaces. A simple lubrication will often clear up minor disturbances which might be mistaken for more serious trouble.

A definite lubrication schedule should be set up taking into consideration the frequency of operation of the breaker and local conditions. Until such a schedule is worked out, the breaker should be lubricated at each periodic inspection and also whenever it is overhauled, in accordance with the lubrication chart, Fig. 14. It is also recommended that all circuit breakers be operated at regular intervals to insure the user that the equipment is operating freely.

The lubrication chart Fig. 14 is divided into two methods of lubrication. The first method outlines the maintenance lubrication which should be performed at the time of periodic maintenance, and requires no disassembly. The second method outlines a lubrication procedure similar to that performed on the breaker at the factory, but should be used only in case of a general overhaul or disassembly for other reasons, or if the operation of the breaker becomes slower.

General Electric Lubricants D50H15 and D50H47 are available in 1/4# collapsible tubes. It is so packaged to insure cleanliness and to prevent oxidation.

**METHOD OF CLEANING BEARINGS**

Wherever cleaning is required, as indicated in the lubrication chart, the following procedures are recommended:

| Part  | Lubrication at Maintenance Period                          | Alternative Lubrication (Requires Disassembly)  |
|---|--|---|
| Ground surfaces such as cams, rollers, latches, etc.          | Wipe clean and apply D50H15.                               | Wipe clean and apply D50H15.  |
| Sleeve Bearings (Mechanism and Breaker Linkage)               | Very light application of light machine oil SAE-20 or -30. | Remove pins and links and clean as per cleaning instructions below. Apply D50H15 liberally. |
| Removable Seal and Open Type Ball, Roller and Needle Bearings | Light application of light machine oil SAE-20 or -30.      | Clean as per cleaning instructions below and repack with D50H15.                            |
| Silver Plated Contacts and Primary Disconnect Studs           | Wipe clean and apply D50H47. △                             | Wipe clean and apply D50H47. △  |
| Arcing Contacts   | Do not lubricate.  | Do not lubricate.   |
| <b>CONTACT ARM HINGE ASSEMBLY</b>                             |  |   |
| 1. Cup Bearing  | No lubrication required.                                   | Wipe clean and apply D50H47. △  |
| 2. Loose rings between bushing and contact arm.               | Wipe clean and apply D50H47. △                             | Wipe clean and apply D50H47. △  |
| Booster Cylinders   | No lubrication required.                                   | No lubrication required.  |

△ NOTE - D50H47 supersedes D50H28.

Fig. 14 Lubrication Chart

Sleeve Bearings

The pins should be removed and all old oxidized grease removed by immersion in clean petroleum solvent or similar cleaner. **DO NOT USE CARBON TETRACHLORIDE.** Wipe the bearing clean. Apply a small amount of G.E. Lubricant D50H15 to the entire surface of the bearing and pin just before reassembling.

Removable Seal and Open Type Ball, Roller and Needle Bearings

The bearings should be first removed from the mechanism and disassembled by the removal of the seals or inner race in the case of needle bearings. They should then be placed in a container of clean petroleum solvent or similar cleaner. **DO NOT USE CARBON TETRACHLORIDE.** If the grease in the bearings has become badly oxidized, it may be necessary to use alcohol (type used for thinning shellac) to remove it. Ordinarily, by agitating the bearings in the cleaning solution, and using a stiff brush to remove the solid particles, the bearings can be satisfactorily cleaned. Do not handle the bearings with bare hands as deposits from the skin onto the bearings are inductive to corrosion. If the bearings are touched, the contamination can be removed by washing in alcohol. After the bearings have been thoroughly cleaned, spin them in clean new light machine oil until the cleaner or solvent is entirely removed. Allow this oil to drain off and then repack them immediately with G. E. Lubricant D50H15 being sure all metal parts are greased. The removable seals should then be replaced.

NOTE: If it becomes necessary to clean the bearings in alcohol (shellac thinner), be sure the alcohol is perfectly clean, and do not allow the bearings to remain in the alcohol more than a few hours. If it is desirable to leave the bearings in the alcohol

for a longer time, an inhibited alcohol such as is used for anti-freeze should be used. Even then the bearings should be removed from the alcohol within twenty-four hours. Esso Anti-Freeze and Du Pont Zerone are satisfactory for this purpose. Precautions against the toxic effects of the alcohol must be exercised by wearing rubber gloves and by using the alcohol in a well ventilated room; excessive exposure to the fumes is sometimes unpleasant to personnel. Washing the bearings in light oil and draining should follow immediately, then apply the lubricant.

**RECOMMENDED MAINTENANCE FOR MAGNE-BLAST BREAKERS APPLIED TO REPETITIVE SWITCHING DUTY**

Magne-blast breakers applied to repetitive operation such as switching arc furnaces, capacitors and motors should be serviced and maintained according to the following schedule:

A. Every 2000 Operations, or Every Six Months - Whichever Comes First

1. Remove the box barriers.
2. Wipe all insulating parts, with a clean dry cloth, including the bushings, clean of smoke deposit and dust, also the inside of the box barriers.
3. Primary Contacts - Inspect the condition of the stationary contact fingers and movable contact blocks. Badly pitted or burned contacts should be replaced. (Note: Burned primary contacts indicate the probable need for arcing contact replacement). If the contact surfaces are only roughened or galled, they should be smoothed with crocus cloth or draw filed. After contact dressing the contacts should be greased lightly with D50H47.



4. Arcing Contacts - When the arcing contact wipe is less than the minimum specified under "ADJUSTMENTS", the contacts should be replaced. The contacts should be inspected for uneven wear and/or damage using a mirror to inspect the stationary contacts. Normally it will not be necessary to remove the arc chutes for this 2000 operation servicing unless inadequate wipe or contact condition indicate a need for replacement. When the arc chutes are removed, the contact braids, coil protectors, and other parts subject to arcing should be checked for possible cleaning or replacement. Do not grease the arcing contacts under any circumstances.
  5. Check the breaker and mechanism adjustments as summarized under "FINAL INSPECTION AND TEST". The necessary readjustments should be made as described under "ADJUSTMENTS".
  6. The breaker and operating mechanism should be carefully inspected for loose nuts, bolts, retaining rings, etc., all cam, latch and roller surfaces should be inspected for damage or excessive wear. The buffer blocks and their retainers on the bottom of the stationary contact support should be inspected for possible need of replacement.
  7. The main contacts of the control device should be inspected for wear and possible replacement.
  8. Lubricate the breaker operating mechanism in accordance with the table under paragraph heading "LUBRICATION".
  9. Inspect all wiring for tightness of connections and possible damage to insulation.
  10. After the breaker has been serviced, it should be slowly closed and opened with the maintenance closing device to be sure there is no binding or friction and that the breaker contacts can move to the fully opened and fully closed positions. Its electrical operation should then be checked using either the test cabinet or the test couplers.
- B. After Every 10,000 Operations**
1. In addition to the servicing done each 2,000 operations, the arc chutes should be removed from the breaker and disassembled to permit a detailed inspection of insulation, blow-out coils, arc runners and assemblies which are contaminated by arc products.
  2. All areas in the throat area of the arc chute should be thoroughly cleaned by using sandpaper. This cleaning should be performed any time the arc chute is removed. The arc chute fins should not be cleaned. Whenever the arc chute is removed, loose dust and dirt should be blown out before replacing arc chutes.
3. The blow-out coils should be carefully examined and if the insulation has been cracked, shrunk or eroded from arc action and heat so that the turns of the coils are not fully insulated from each other, the coils should be replaced. All connections should be checked for tightness.
  4. The arc runners should be inspected and replaced when any part of their area has been reduced to 25% of the original metal thickness as a result of arc erosion.
  5. Check the stationary arc contacts to assure that the arcing contacts are in good condition and that their connections are tight.
  6. Insulating material that is carbonized and cannot be satisfactorily cleaned should be replaced.
  7. Any parts damaged or severely burned and/or eroded from arc action should be replaced.  
NOTE: Fine cracks may develop in the fins of the arc chute sides. This is to be expected with ceramic materials when subjected to the high heat of an arc and may be disregarded unless they are long and present a possibility of fin sections breaking completely off. Small broken corners on the exhaust end of the arc chute will not interfere with its performance and can also be disregarded.
  8. The cup bearing and the contact ring at the hinge point of the contact blade should be disassembled, inspected, cleaned and re-lubricated with G. E. contact lubricant D50H47. The contact ring should be inspected for wear and replaced when reduced in thickness to less than 1/32".
- C. Every 20,000 Operations or Approximately Every Five Years - Whichever Comes First**
1. At this time the breaker should be given a general overhaul and all excessively worn parts in both the mechanism and breaker replaced. Such wear will usually be indicated when the breaker cannot be adjusted to instruction book tolerances. This overhaul and inspection is more detailed and will require disassembly of mechanism and breaker operating parts.
  2. The trip roller and trip shaft bearings in the operating mechanism should be disassembled, cleaned and repacked with G.E. Lubricant D50H15 as described under "LUBRICATION".
  3. The stationary primary contact fingers should be disassembled and the silver-plated pivot area of the contact and contact support cleaned and lubricated with G.E. lubricant D50H47.
  4. The breaker and operating mechanism should be serviced as described

for every 2,000 operations and properly adjusted before being put back into service.

#### TROUBLE SHOOTING


Failure of a breaker to operate properly will generally fall within three general classes; failure to trip, failure to close or latch closed, and overheating. The following is a brief outline showing particular types of distress that might be encountered, together with suggestions for remedying the trouble:

#### FAILURE TO TRIP

1. Mechanism binding or sticking caused by lack of lubrication.  
REMEDY: Lubricate complete mechanism.
2. Mechanism binding or sticking caused by being out of adjustment.  
REMEDY: Check all mechanism adjustments, latches, stops, auxiliary devices, etc., in accordance with INSTALLATION, ADJUSTMENTS. Examine latch and roller surfaces for corrosion.
3. Damaged trip coil.  
REMEDY: Replace damaged coil.
4. Blown fuse in trip circuit.  
REMEDY: Replace blown fuse after determining cause of failure.
5. Faulty connections in trip circuit.  
REMEDY: Repair broken or loose wires and see that all binding screws are tight.
6. Damaged or dirty contacts in trip circuit.  
REMEDY: Recondition or replace contacts.


#### FAILURE TO CLOSE OR LATCH CLOSED

1. Mechanism binding or sticking caused by lack of lubrication.  
REMEDY: Lubricate complete mechanism.
2. Mechanism binding or sticking caused by being out of adjustment.  
REMEDY: Check all mechanism adjustments, latches, stops, auxiliary devices, etc., in accordance with INSTALLATION, ADJUSTMENTS. Examine latch and roller surfaces for corrosion.
3. Control device sticking or not operating properly.  
REMEDY: Check and adjust control device, or replace.
4. Damaged or dirty contacts in control circuit including control device.  
REMEDY: Recondition or replace contacts.
5. Damaged control device coil.  
REMEDY: Replace damaged coil.
6. Damaged closing coil.  
REMEDY: Replace damaged coil.
7. Defective cut-off switch, latch-checking switch, or interlock switch.  
REMEDY: Replace defective switch.




- |                             |                               |
|-----------------------------|-------------------------------|
| 1. Rear Bushing             | 7. Arc Chute Mounting Bracket |
| 2. Supporting Bolt          | 8. Lower Mounting Support     |
| 3. Upper Mounting Support   | 9. Lower Supporting Bolt      |
| 4. Movable Arcing Contact   | 10. Upper Horizontal Barrier  |
| 5. Assembly Bolts           | 11. Lower Horizontal Barrier  |
| 6. Side Brace for Arc Chute |                               |

Fig. 15 Removal of Arc Chute Assembly




- |                      |                            |
|----------------------|----------------------------|
| 1. Assembly Bolts    | 10. Assembly Bolts         |
| 2. Assembly Bolts    | 11. Assembly Bolts         |
| 3. Upper Pole Pieces | 12. Assembly Bolts         |
| 4. Lower Pole Pieces | 13. Upper Mounting Support |
| 5. Rear Brace        | 14. Side Brace             |
| 6. Assembly Bolt     | 15. Assembly Bolts         |
| 7. Assembly Bolt     | 16. Lower Mounting Support |
| 8. Lower Brace       | 17. Assembly Bolts         |
| 9. Assembly Bolts    | 18. Assembly Bolts         |
|                      | 19. Upper Insulation       |

Fig. 16 Arc Chute Assembly Complete



- |                              |                              |
|------------------------------|------------------------------|
| 1. Upper Arc Runner Spacers  | 7. Upper Insulation          |
| 2. Upper Arc Runner Assembly | 8. Lower Arc Runner          |
| 3. Blowout Core              | 9. Lower Arc Runner Assembly |
| 4. Blowout Coil              | 10. Lower Arc Runner Spacers |
| 5. Upper Arc Runner          | 11. Lower Coil Connection    |
| 6. Arc Chute Side            |                              |

Fig. 17 Arc Chute Assembly with Sides Removed



- |                              |
|------------------------------|
| 1. Upper Mounting Support    |
| 2. Connection Bolt           |
| 3. Upper Arc Runner Assembly |
| 4. Upper Arc Runner          |
| 5. Side Shield               |
| 6. Lower Arc Runner Assembly |
| 7. Lower Coil Connection     |
| 8. Connection Nut            |

Fig. 18 Front View - Arc Chute Assembly

8. Blown fuse in closing circuit.  
**REMEDY:** Replace blown fuse after determining cause of failure.

9. Faulty connections in closing circuit.  
**REMEDY:** Repair broken or loose wires and see that all binding screws are tight.

10. Insufficient control voltage caused by excessive drop in leads.  
**REMEDY:** Install larger wires and improve electrical contact at connections.

11. Insufficient control voltage caused by poor regulation (a-c control).  
**REMEDY:** Install larger control transformer. Check rectifier to be sure it is delivering adequate d-c supply.

#### OVERHEATING

1. Poor condition of contacts due to lack of attention after severe duty or too frequent operation.

**REMEDY:** Recondition or replace burned and pitted contacts. (Contacts should be reconditioned very carefully and only when absolutely necessary).

2. Contacts not properly aligned or adjusted.

**REMEDY:** Check all adjustments in accordance with INSTALLATION, ADJUSTMENTS.

3. Breaker kept closed or open for too long a period.

**REMEDY:** Operate breaker more often to wipe contacts clean. Replace contacts if necessary.

4. Overloading.

**REMEDY:** Replace breaker with one of adequate rating for present or future load, or re-arrange circuits so as to remove excess load.

5. Primary connections of inadequate capacity.

**REMEDY:** Increase size or number of conductors or remove excess current.

6. Loose connections or terminal connectors.

**REMEDY:** Tighten.

7. Ambient temperature too high.

**REMEDY:** Relocate in a cooler place, or arrange some means of cooling.

#### REPAIR AND REPLACEMENT

The following information covers in detail the proper method of removing various parts of the breaker in order to make any necessary repairs. This section includes only those repairs that can be made at the installation on parts of the breakers that are most subject to damage or wear. **IMPORTANT: UPON COMPLETION OF ANY REPAIR WORK, ALL BREAKER AND MECHANISM ADJUSTMENTS MUST BE CHECKED. Refer to the sections on ADJUSTMENTS and FINAL INSPECTION.**

#### ARC CHUTE - TO INSPECT OR REPLACE BLOWOUT COILS

To remove an arc chute, first open the breaker and remove the box barrier (2), Fig. 4. Loosen the two upper supporting bolts (2), Fig. 15, and the one lower supporting bolt (9), Fig. 15, using a 3/4" wrench. By raising the complete arc chute assembly about 1/2" and sliding it toward the rear of the breaker, it can be removed. This operation may be accomplished with the aid of an arc chute lifter.

To disassemble the arc chute after it has been removed from the breaker, proceed as follows:

1. Remove the assembly bolts (2, 7, 9, 10, 12, and 15), Fig. 16.

2. Remove the side brace (14), and rear brace (5), the upper pole pieces (3), and the lower pole pieces (4), Fig. 16.

3. To remove the upper mounting support (13), Fig. 16, remove the assembly bolts (1 and 11), Fig. 16, and the connection bolt (2), Fig. 18.

4. Remove the assembly bolts (18) to remove the lower brace (8), Fig. 16.

5. Remove the lower mounting support (16) by removing the assembly bolts (17), Fig. 16, and the connection nut (8), Fig. 18.

6. At this point, the fiber side shields (5), Fig. 18, and the upper arc runner assembly (3) can be removed.

7. Further disassembly of both the upper and lower arc runner assemblies can be done by removing the various screws and 1/4" assembly bolts (not illustrated) as shown in Fig. 17.

8. The arc chute sides (6), Fig. 17, can be separated by removal of the assembly bolt (6), Fig. 16.

Reassemble the arc chute in the reverse order. The following items should be noted during reassembly:

1. Equally space the fins of the arc chute sides before bolting together.

2. Check to insure that electrical connections to the blowout coils are tight.

3. When reassembling the arc runner assemblies, check that the spacers (1 and 10), Fig. 17, are correctly installed.

4. Before bolting the upper mounting support in place, make certain that the upper arc runner assembly is tight against the arc chute side so that the gap between the upper insulation (7), Fig. 17, and the arc chute side (6) is a minimum.

5. Make certain that the electrical connections (2 and 8), Fig. 18, are tight.

To reassemble the arc chute to the breaker, proceed as follows:

1. Rest the lower mounting support (8) on the arc chute mounting bracket (7) as shown in Fig. 15.

2. Slide the arc chute forward and lift it slightly to engage the supporting bolts (2), Fig. 15, in the slots of the upper mounting support (3).

3. Check the spring baffle (11), Fig. 19, to assure that it closes the gap between upper insulation (19), Fig. 16, and the back of the contact support (4), Fig. 19.

4. Tighten the supporting bolts (2 and 9) Fig. 15. These bolts serve as both the electrical and mechanical connections between the bushing and the arc runners.

5. Check that the movable arcing contact (4), Fig. 15, passes between the probes on the upper arc runner (5) Fig. 17 without touching.

#### TRIP SHAFT BALL BEARINGS

1. Remove mounting bolts for control device, Fig. 1, Part 7, letting control device hang free. Do not remove wiring.

2. Remove the trip coil frame mounting bolts, Fig. 24, Part 2, letting frame hang free. Also, remove trip coil leads from terminal boards, Fig. 24, Part 4.

3. Remove the trip coil and plunger bracket from trip shaft using snap ring pilers on ring holding trip coil plunger assembly.


4. Remove switch bar, Fig. 23, Part 5, from latch shaft and snap ring and washers near bearing.

5. Remove stop bar, Fig. 31, View A, Part 282, for manual trip rod. Also, remove snap rings and washers next to bearing on left side.

6. Using a brass rod approximately 15" long and 3/8" diameter, drive each bearing out, taking the right one out first using the opening in the left side of mechanism frame and the left one out from the opening made from the removal of the right hand bearing. **NOTE:** When removing the left hand bearing, brass rod as mentioned above may have to be bent in order to clear latch.


7. To reassemble, reverse the above procedure except to drive bearings back in the mechanism frame, a pipe should be used so as not to damage bearing surface.

**NOTE:** If latch is to be replaced, the first seven steps as listed above should be followed. Also remove the set screw holding the latch on shaft then place block between latch and frame to stop movement, and drive shaft out of latch. When replacing, make sure spring is in proper place and one half turn has been made to wind spring. Also, make sure latch is in place on stop bar roller before bearings and shaft are reassembled.



- |                                    |                            |  |
|------------------------------------|----------------------------|--|
| 1. Rear Bushing                    | 4. Contact Support         | 8. Connection Bolt                     |
| 2. Guide and Support for Arc Chute | 5. Bolt for Flexible Braid | 9. Stud for Mounting Arcing Fingers    |
| 3. Bolts for Contact Support       | 6. Mounting Bolt           | 10. Stationary Arcing Contact Assembly |
|                                    | 7. Flexible Braid          | 11. Spring Baffle                      |

Fig. 19 Rear Bushing Assembly



- |                                 |                                      |                                       |
|---------------------------------|--------------------------------------|---------------------------------------|
| 1. Spring Guide                 | 4. Spring Retainer                   | 7. Contact Support                    |
| 2. Handle for Spring Compressor | 5. Assembly Bolt for Spring Retainer | 8. Stop Plate                         |
| 3. Spring Compressor            | 6. Spring                            | 9. Stationary Primary Contact Fingers |

Fig. 20 Method of Installing Primary Contact Springs Using a Spring Compressor

TRIP LATCH ROLLER BEARING

1. Remove mounting bolts on control device, Fig. 1, Part 7, letting control device hang free. Do not remove wiring.
2. Place block between manual trip rod Fig. 1, Part 6, and stop bar on trip shaft. This holds trip shaft in trip position and allows trip linkage to be free.
3. Working through hole on left hand side of mechanism, remove snap ring and washer from trip roller pin, Part 289, Fig. 31, View C, using snap ring pliers.
4. Slide trip roller pin, Part 289, Fig. 31, just enough to the right to allow room to hook snap ring pliers on ring on other end of pin. Compress pliers to free snap ring and pry the pin to the left with screwdriver to complete the removal of snap rings.
5. Trip roller bearing can now be removed for lubrication (see section on LUBRICATION). Particular attention should be paid to the location of washers and spacers.
6. To reassemble, reverse the above procedures.

CONTACTS

Open the breaker and remove the box barrier and arc chutes as previously described. To remove the contacts, proceed as follows:

A. Stationary Arcing Contacts (10), Fig. 19

1. Disconnect the contact braids from contact fingers by removing two bolts (8), Fig. 19.
2. Grasp the lower end of the contact fingers with pliers and pull contact assembly downward to remove from stud assembly.
3. To disassemble braids from stud assembly, remove one bolt (5).
4. To disassemble stud assembly from contact support, remove two bolts (6).
5. Reassemble in the reverse order.

B. Stationary Primary Contacts (9), Fig. 20

1. Compress the contact spring (6).
2. Remove spring and spring guide (1).
3. Raise the contact finger to clear the primary contact stop plate (8) and lift the finger out of contact support (7). Remove one contact finger at a time.

To replace the Stationary Primary Contacts:

1. Apply a thin coating of D50H47 grease on the hinged edge of the finger (9) then place it on the contact support (7) so that it is retained by stop plate (8).
2. Open spring compressor (3) and assemble spring guide, spring and spring compression (Fig. 20A).

Fig. 19 (8021450)

Fig. 20 (8017149)

3. Turn handle (2) in clockwise direction to compress contact spring (Fig. 18B). Hold spring firmly in yoke on spring compressor to prevent spring from slipping out of the compressor.
4. Place washer (not shown) on guide on top of spring, place top of guide into hole in spring retainer (4) and the round end of spring guide in cut-out in primary finger (Fig. 20C).
5. Hold spring assembly firmly in place and remove spring compressor.

C. Movable Arcing Contact (7), Fig. 21

1. Remove the assembly bolts (8).
2. Reassemble in reverse order.

D. Movable Primary Contacts (5), Fig. 21 (1200 Amp. Breaker)

1. Remove the nuts from assembly bolts (6).
2. Remove the primary contacts and spacers (not illustrated).
3. Reassemble in reverse order.

(2000 Amp. Breaker)

1. Remove the nuts from assembly bolts (6).
2. Remove the connection bar (9).
3. Remove the cup bearing (3).
4. Spread the contact arms (4) and remove the primary contacts (5).
5. Reassemble in the reverse order.

E. Contact Blade Assembly (4,5,7) Fig. 21


1. Remove the connection bar (9).
2. Remove the cup bearing (3) and the pin (2), Fig. 7.
3. When reassembling, first insert the piston assembly (10), Fig. 21, into the booster cylinder and reassemble the cup bearing (3).
4. Replace pin (2), Fig. 7, and connection bar (9), Fig. 21.

F. After disassembly and reassembly of any contacts, check all contact adjustments as described under INSTALLATION, ADJUSTMENTS.

BUSHINGS

**IMPORTANT: DO NOT REMOVE ALL SIX BUSHINGS AT ONCE.** The bushings have been carefully aligned with the breaker frame, during assembly at the factory, and it is important that this alignment be maintained to facilitate installation of the breaker in the metal-clad unit. It is therefore recommended that the bushings be removed and reassembled one at a time. Also, before removing any one bushing, measure the distance from that particular bushing to adjacent bushings in both directions, so that it may be reinstalled in the same location.

It is also possible to remove and reassemble three bushings at one time. If this is preferred, alignment of the bushings may be accomplished by placing the breaker in a de-energized spare metal-clad unit before tightening the bushing mounting bolts. This must be done before the arc chutes are reinstalled.



1. Contact Springs
2. Stationary Primary Contacts
3. Cup Bearing
4. Contact Arm
5. Movable Primary Contacts
6. Assembly Bolts
7. Movable Arcing Contact
8. Assembly Bolts
9. Connection Bar
10. Piston Assembly

Fig. 21 Removal of Contacts

To replace the bushing, proceed as follows:

Rear Bushing

1. Open the breaker and remove the box barrier and arc chutes as already described.
2. Remove the upper and lower horizontal barriers (10 and 11), Fig. 15.
3. Remove the four bolts (12) at the mounting flange of the rear bushing being removed and lower the bushing assembly.
4. Referring to Fig. 20, disassemble the primary contact springs (6) as previously described.
5. Disassemble the spring retainer (4) by removing mounting bolts (5).
6. Referring to Fig. 19, disassemble the contact support (4) and arc chute mounting bracket (2) by removing two bolts (3).
7. Reassemble in the reverse order. The arc chute mounting bracket (2) is not symmetrical and must be assembled correctly to orient the arc chute properly on the breaker. The longest projection of the bracket should be toward the lower end of the bushing.

Front Bushing

1. Open the breaker and remove the box barrier and arc chutes as already described.
2. Remove the upper and lower horizontal barriers (10 and 11), Fig. 15.
3. Remove the connection bar (9), Fig. 21, and cup bearing (3).
4. Remove the four bolts at the mounting flange of the front bushing being removed, and lower the bushing.
5. When reassembling, first mount the bushing and assemble the cup bearing (3) and contact arm (4), Fig. 21. The contact surfaces at the hinge point of the contact blade and bushing should have a thin coating of D50H47 grease.
6. Check all contact adjustments as outlined under INSTALLATION, ADJUSTMENTS.

CLOSING COIL

The closing coil is contained within the solenoid pot (1), Fig. 22. To remove the closing coil, proceed as follows:

1. Open the breaker.
2. Remove the two closing coil leads (10). Remove the terminal board

Fig. 21 (8021969)

(2) from the solenoid pot and let it hang by the wires. Also, remove the wire cleat band (3).

- Remove the stop nuts (7 and 12) on guide studs (11), lower the armature plate (6) and control device trip plunger (5).

**NOTE:** For ease in removing the closing coil and bottom plate (step 5) the armature and plunger assembly can be removed from the mechanism by removing the four bolts on the underside of the armature plate.

- Loosen the four nuts under the bottom plate (4) approximately 1/2". Support the bottom plate with a rope sling or hoist and remove the two rear nuts.
- Remove the nuts (8) at the top of the front studs. This permits the bottom plate, closing coil, solenoid pot (1) and control device plunger guide (9) to be removed.
- To reassemble, first place the closing coil and spacers on the bottom plate (4). Raise into position, inserting the control device plunger guide (9) and compressing the piston ring on the upper pole piece.
- Tilt the bottom plate downward and replace the solenoid pot (1) and two front studs and nuts (8).
- Tighten the four nuts under the bottom plate taking special precaution to center the closing coil around the pole piece. If the closing coil is not firmly held in place, add spacers above the closing coil.
- Replace the control device trip plunger (5) and armature (6).
- Recheck the mechanism adjustments as explained under **INSTALLATION, ADJUSTMENTS.**


#### TRIP COIL

To replace the potential trip coil (3), Fig. 24, proceed as follows:

- Open the breaker and remove the opening spring unit (2), Fig. 23, by removing the pivot pins (1 and 3).
- Disconnect the two trip coil lead wires (4), Fig. 24.
- Remove the two mounting bolts (2) and the trip coil support (1).
- Remove the trip coil (3).
- After reassembling (in the reverse order) check the primary contact gap adjustment as explained under **INSTALLATION, ADJUSTMENTS.**


#### INTERLOCK SWITCH

To remove the interlock switch (4), Fig. 9, remove the two mounting screws and disconnect the lead wires. Reassemble in the reverse order and check the switch adjustments as explained under **INSTALLATION, ADJUSTMENTS.**



- |                                    |                        |
|------------------------------------|------------------------|
| 1. Solenoid Pot                    | 7. Stop Nuts           |
| 2. Terminal Board                  | 8. Front Stud Nuts     |
| 3. Secondary Wire Cleats           | 9. Plunger Guide       |
| 4. Bottom Plate                    | 10. Closing Coil Leads |
| 5. Control Device Trip Plunger Rod | 11. Guide Studs        |
| 6. Closing Armature                | 12. Stop Nuts          |

Fig. 22 Closing Solenoid Assembly



- |                              |
|------------------------------|
| 1. Pivot Pin                 |
| 2. Opening Spring Unit       |
| 3. Pivot Pin                 |
| 4. Trip Coil Mounting Frame  |
| 5. Switch Bar                |
| 6. Trip Coil Plunger Bracket |

Fig. 23 Opening Spring Assembly

Fig. 22 (8024690)


Fig. 23 (8024689)

**LATCH CHECKING SWITCH**

To remove the latch checking switch (7), Fig. 9, (when furnished), remove the two mounting screws and disconnect the lead wires. Reassemble in the reverse order and check the switch adjustments as explained under INSTALLATION, ADJUSTMENTS.

**CUT-OFF SWITCH**

To remove the cut-off switch (1), Fig. 11, remove the two mounting bolts and disconnect the lead wires. When reassembling, check the cut-off switch adjustment as explained under INSTALLATION, ADJUSTMENTS.



- 1. Trip Coil Support
- 2. Mounting Bolts
- 3. Trip Coil
- 4. Trip Coil Leads

Fig. 24 Potential Trip Coil

Fig. 24 (8019962)



## RENEWAL PARTS

It is recommended that sufficient renewal parts be carried in stock to enable the prompt replacement of any worn, broken, or damaged parts. A stock of such parts minimizes service interruptions caused by breakdowns, and saves time and expense.

When continuous operation is a primary consideration, more renewal parts should be carried, the amount depending upon the severity of the service and the time required to secure replacements.

Renewal parts which are furnished may not be identical to the original parts, since improvements are made from time to time. The parts which are furnished, however, will be interchangeable.

NOTE: The listed terms "right" and "left" apply when facing the solenoid mechanism end of the breaker.

### ORDERING INSTRUCTIONS

1. ALWAYS SPECIFY THE COMPLETE NAMEPLATE DATA OF BOTH THE BREAKER AND THE MECHANISM.
2. SPECIFY THE QUANTITY, CATALOG NUMBER (IF LISTED), REFERENCE NUMBER (IF LISTED), AND DESCRIPTION OF EACH PART ORDERED, AND THIS BULLETIN NUMBER.
3. STANDARD HARDWARE, SUCH AS SCREWS, BOLTS, NUTS, WASHERS, ETC., IS NOT LISTED IN THIS BULLETIN. SUCH ITEMS SHOULD BE PURCHASED LOCALLY.
4. FOR PRICES, REFER TO THE NEAREST OFFICE OF THE GENERAL ELECTRIC COMPANY.

### ILLUSTRATION REFERENCE

|   | FIG. | PAGE |
|---|------|------|
| Arc Chute   | 27   | 24   |
| Control Device for All Mechanisms                     | 38   | 36   |
| Cross-sections - Type AM 13.8-3                       | 25   | 22   |
| Impact Trip Device for All Mechanisms                 | 37   | 35   |
| Interlock Plunger                                     | 30   | 29   |
| Maintenance Closing Device                            | 34   | 33   |
| Movable Contact Arm Assembly                          | 29   | 28   |
| MS-13 Mechanism-Cross-section, Details, Spring Asm.   | 31   | 30   |
| MS-13 Mechanism, Front View, Right and Left Side View | 32   | 32   |
| MS-13 Mechanism, with Current Trip, Partial View      | 35   | 34   |
| Rear Bushing Assembly                                 | 28   | 26   |
| Secondary Disconnect Device and Mechanism Parts       | 33   | 33   |
| Undervoltage Device                                   | 36   | 34   |



## PARTS RECOMMENDED FOR NORMAL MAINTENANCE

In the tabulation below are listed the parts of those breakers which are usually recommended for stock for normal maintenance. Other parts are listed on the following pages.

| FIG. NO. | REF. NO. | RATING IN MVA                      | RATING IN AMPS | CAT. NO. FOR TYPE AM-13.8(MVA)-3 | NO. PER BKR. | DESCRIPTION                                  |
|----------|----------|------------------------------------|----------------|----------------------------------|--------------|--|
| 25       | 9        | ALL                                | ALL            | 263B292 P-2                      | 3            | Booster Cylinder                             |
| 25       | 16       | ALL                                | ALL            | 281B708 G-1                      | 3            | Operating Rod Assembly                       |
| 28       | 165      | (150, 250, 500<br>150A, 250A, 500A | 1200           | 236C791 P-8                      | 12           | Contact Finger                               |
| 28       | 165      | 500B, 500AB                        | 1200           | 236C791 P-8                      | 24           | Contact Finger                               |
| 28       | 165      | ALL                                | 2000           | 236C791 P-8                      | 24           | Contact Finger                               |
| 29       | 211      | ALL                                | ALL            | 802B742 G-3                      | 3            | Movable Arcing Contact                       |
| 28       | 156      | ALL                                | ALL            | 236C790 G-9                      | 3            | Stationary Arcing Contact Assembly           |
| 29       | 212      | (150, 250, 500<br>150A, 250A, 500A | 1200           | 6591644 P-7                      | 3            | Movable Primary Contact                      |
| 29       | 212      | 500B, 500AB                        | 1200           | 6591644 P-7                      | 6            | Movable Primary Contact                      |
| 29       | 212      | ALL                                | 2000           | 6591644 P-7                      | 6            | Movable Primary Contact                      |
| 29       | 213      | (150, 250, 500<br>150A, 250A, 500A | 1200           | 6591644 P-8                      | 3            | Movable Primary Contact                      |
| 29       | 213      | 500B, 500AB                        | 1200           | 6591644 P-8                      | 6            | Movable Primary Contact                      |
| 29       | 213      | ALL                                | 2000           | 6591644 P-8                      | 6            | Movable Primary Contact                      |
| 28       | 160      | (150, 250, 500<br>150A, 250A, 500A | 1200           | 414A180                          | 12           | Spring                                       |
| 28       | 160      | 500B, 500AB                        | 1200           | 6509787 P-1                      | 24           | Spring                                       |
| 28       | 160      | ALL                                | 2000           | 6509787 P-1                      | 24           | Spring                                       |
| 27       | 143      | ALL                                | ALL            | 688C583 P-12                     | 6            | (Mycalex) Upper                              |
| 27       | 156      | ALL                                | ALL            | 414A116 P-2                      | 3            | Insulation                                   |
| 27       | 167      | ALL                                | ALL            | 619C488 G-1                      | 6            | (Mycalex) Lower Shield                       |
| 28       | 155L     | ALL                                | ALL            | 236C791 G-1                      | 3            | Flexible Connector                           |
| 28       | 155R     | ALL                                | ALL            | 236C791 G-4                      | 3            | Flexible Connector                           |
| 28       | 158      | ALL                                | ALL            | 414A116 P-4                      | 3            | Insulation Plate (Mycalex)                   |
| 28       | 159      | ALL                                | ALL            | 6445087 P-1                      | 3            | Buffer                                       |
| 28       | 168      | (150, 250, 500<br>150A, 250A, 500A | 1200           | 6557243 P-1                      | 6            | Clamp For Buffer                             |
| 28       | 168      | 500A, 500AB                        | 1200           | 6557243 P-2                      | 6            | Clamp For Buffer                             |
| 28       | 168      | ALL                                | 2000           | 6557243 P-2                      | 6            | Clamp For Buffer                             |
| 30       | 261      | 500                                | ALL            | 6375521 G-2                      | 1            | Closing Coil 125 v d-c or 230 v a-c          |
| 30       | 261      | 150 & 250                          | ALL            | 6375521 G-6                      | 1            | Closing Coil 125 v d-c or 230 v a-c          |
| 30       | 261      | 500                                | ALL            | 6375521 G-1                      | 1            | Closing Coil 250 v d-c                       |
| 30       | 261      | 150 & 250                          | ALL            | 6375521 G-5                      | 1            | Closing Coil 250 v d-c                       |
| 30       | 261      | 500B                               | ALL            | 6375521 G-4                      | 1            | Closing Coil 110 v d-c                       |
| 30       | 261      | 500B                               | ALL            | 6375521 G-3                      | 1            | Closing Coil 220 v d-c                       |
| 32       | 370      | ALL                                | ALL            | 6174582 G-1                      | 1            | Potential Trip Coil 125 v d-c                |
| 32       | 370      | ALL                                | ALL            | 6174582 G-2                      | 1            | Potential Trip Coil 250 v d-c                |
| 32       | 370      | ALL                                | ALL            | 6174582 G-14                     | 1            | Potential Trip Coil 230 v a-c                |
| 32       | 370      | ALL                                | ALL            | 6275070 G-1                      | 1            | Potential Trip Coil 24 v d-c                 |
| 32       | 370      | ALL                                | ALL            | 6275070 G-2                      | 1            | Potential Trip Coil 48 v d-c                 |
| 36       | 663      | ALL                                | ALL            | 6275017 G-19                     | 1            | Undervoltage Device Coil 125 v d-c           |
| 36       | 663      | ALL                                | ALL            | 6275017 G-33                     | 1            | Undervoltage Device Coil 230 v a-c           |
| 36       | 663      | ALL                                | ALL            | 6275017 G-20                     | 1            | Undervoltage Device Coil 250 v d-c           |
| 38       | 753      | ALL                                | ALL            | 6275017 G-19                     | 1            | Control Device Coil 125 v d-c                |
| 38       | 753      | ALL                                | ALL            | 6275017 G-33                     | 1            | Control Device Coil 230 v a-c (cont.)        |
| 38       | 753      | ALL                                | ALL            | 6275017 G-20                     | 1            | Control Device Coil 250 v d-c                |
| 36       | 753      | ALL                                | ALL            | 6275017 G-34                     | 1            | Control Device Coil 230 v a-c (intermittent) |




FIG. A




FIG. B




FIG. B

Fig. 25 Cross Section Type AM-13.8-3




Fig. 26 Cross Section

Fig. 25 (2540739)

Fig. 26 (2366792)

| REF. NO. | MVA                        | AMPS. | CAT. NO. FOR AM 13.8 (MVA)-3 | NO. REQ. | DESCRIPTION                  |
|----------|----------------------------|-------|------------------------------|----------|------------------------------|
| 1        | ALL                        | 1200  | 258C680 P-11                 | 1        | Top Plate                    |
| 1        | ALL                        | 2000  | 258C680 P-10                 | 1        | Top Plate                    |
| 2        | ALL                        | 1200  | 215D479 P-14                 | 1        | Angle                        |
| 2        | ALL                        | 2000  | 215D479 P-23                 | 1        | Angle                        |
| 3        | ALL                        | ALL   | 281B764 G-1                  | 1        | Handle                       |
| 4        | ALL                        | ALL   | 265C151 P-28                 | 3        | Box Barrier Clamp            |
| 5        | ALL                        | ALL   | 258C680 P-6                  | 6        | Arc Chute Support            |
| 6        | ALL                        | ALL   | 258C619 G-6                  | 3        | Arc Chute Clamp              |
| 7        | ALL                        | ALL   | 258C614 P-5                  | 3        | Block                        |
| 8        | ALL                        | ALL   | 456A329 G-1                  | 3        | Vertical Barrier             |
| 9        | ALL                        | ALL   | 263B292 P-2                  | 3        | Booster Cylinder             |
| 10       | ALL                        | ALL   | 265C151 P-30                 | *        | Shim                         |
| 11       | ALL                        | 1200  | 265C842 G-2                  | 3        | Bushing (Long)               |
| 11       | ALL                        | 2000  | 265C188 G-5                  | 3        | Bushing (Long)               |
| 12       | ALL                        | ALL   | 6048229 P-1                  | *        | Shim                         |
| 13       | ALL                        | 1200  | 258C614 G-4                  | 3        | Horizontal Barriers (Lower)  |
| 13       | ALL                        | 2000  | 258C614 G-1                  | 3        | Horizontal Barriers (Lower)  |
| 14       | ALL                        | 1200  | 258C614 P-31                 | 6        | Horizontal Barriers (Upper)  |
| 14       | ALL                        | 2000  | 258C614 P-32                 | 6        | Horizontal Barriers (Upper)  |
| 15       | ALL                        | ALL   | 265C162 P-17                 | 2        | Side Barrier                 |
| 16       | ALL                        | ALL   | 281B708 G-1                  | 3        | Operating Rod Assembly       |
| 17       | ALL                        | ALL   | 265C160 P-22                 | 3        | Connection Bar               |
| 18       | (150, 150A<br>(250, 250A   | ALL   | 265C176 G-2                  | 3        | Box Barrier Assembly         |
| 18       | (500, 500A<br>(500B, 500BA | ALL   | 265C176 G-1                  | 3        | Box Barrier Assembly         |
| 18A      | (150, 150A<br>(250, 250A   | ALL   | 421A218 G-1                  | 6        | Muffler                      |
| 18A      | (500, 500A<br>(500B, 500BA | ALL   | 264B171 G-3                  | 6        | Muffler                      |
| 19       | ALL                        | ALL   | 265C170 G-1                  | 1        | Box Barrier Guide            |
| 20       | ALL                        | ALL   | 265C170 P-5                  | 1        | Box Barrier Guide Support    |
| 21       | ALL                        | ALL   | 265C170 P-11                 | 1        | Box Barrier Guide Support    |
| 21       | △                          | △     | 265C170 P-12                 | 1        | Box Barrier Guide Support    |
| 22       | ALL                        | ALL   | 258C683 G-2                  | 1        | Wheel Assembly Complete      |
| 23       | △                          | △     | 236C768 G-10                 | 1        | Wheel Assembly Complete      |
| 24       | ALL                        | ALL   | 258C683 P-18                 | 2        | Wheel & Spanner Bushing      |
| 25       | ALL                        | ALL   | 258C683 P-19                 | 2        | Front Wheel & Caster         |
| 26       | △                          | △     | 6597296 P-7                  | 2        | Wheel                        |
| 27       | △                          | △     | 236C768 G-7                  | 2        | Front Wheel & Caster         |
| 30       | ALL                        | 1200  | 421A239 P-1                  | 3        | Spring                       |
| 31       | ALL                        | 1200  | 6442371 P-1                  | 3        | Bearing                      |
| 32       | ALL                        | 1200  | 414A106 P-4                  | 3        | Screw                        |
| 33       | ALL                        | ALL   | 6441617 P-1                  | 3        | Washer                       |
| 34       | ALL                        | ALL   | 456A884 P-1                  | 6        | Loose Rings                  |
| 35       | ALL                        | 2000  | 6442258 P-1                  | 3        | Stud                         |
| 36       | ALL                        | 2000  | 6442246 P-1                  | 6        | Spacer                       |
| 37       | ALL                        | 2000  | 6441630 P-1                  | 3        | Washer                       |
| 38       | ALL                        | 2000  | 6442257 P-1                  | 3        | Bearing                      |
| 39       | ALL                        | 2000  | 369A407 P-1                  | 3        | Spring                       |
| **39A    | ALL                        | 1200  | 898B282 G-1                  | 3        | Hinge Pin Assembly, Complete |
| **39A    | ALL                        | 2000  | 898B282 G-2                  | 3        | Hinge Pin Assembly, Complete |

△ Those Breaker Model List Numbers With "W" Suffix.

\* As Required.

\*\* This Assembly Includes Parts 33 to 39 Inclusive.




Fig. 27A Complete Assembly




Fig. 27C Front View

Fig. 27A (8022405)

Fig. 27B (8022401)

Fig. 27C (8022402)




Fig. 27B Component Parts

Fig. 27 Arc Chute

## PARTS REFERENCED IN FIGS. 27A, 27B &amp; 27C FOR ALL RATINGS

| REF. NO. | CAT. NO. FOR AM 13.8 (MVA)-3 | NO. PER BREAKER | DESCRIPTION                      |
|----------|------------------------------|-----------------|----------------------------------|
| 100      | 108B1917 G-1                 | 3               | Arc Chute Assembly & Clamp       |
| 101      | 264B100 G-7                  | 3               | Arc Chute Sides                  |
| 102      | 265C150 G-3                  | 3               | Upper Support                    |
| 103      | 258C615 P-15                 | 3               | Lower Support                    |
| 104      | 265C161 P-6                  | 6               | Lower Brace                      |
| 105L     | 265C161 P-5                  | 3               | Rear Brace (Left)                |
| 105R     | 265C161 P-15                 | 3               | Rear Brace (Right)               |
| 106L     | 265C162 P-16                 | 3               | Side Brace (Left)                |
| 106R     | 265C162 P-26                 | 3               | Side Brace (Right)               |
| 107      | 265C163 P-4                  | 6               | Shield                           |
| 108L     | 265C162 P-4                  | 3               | Upper Pole Piece                 |
| 108R     | 265C162 P-7                  | 3               | Upper Pole Piece                 |
| 109L     | 265C162 P-3                  | 3               | Upper Pole Piece                 |
| 109R     | 265C162 P-6                  | 3               | Upper Pole Piece                 |
| 110L     | 265C162 P-2                  | 3               | Upper Pole Piece                 |
| 110R     | 265C162 P-5                  | 3               | Upper Pole Piece                 |
| 111L     | 265C162 P-10                 | 3               | Lower Pole Piece                 |
| 111R     | 265C162 P-13                 | 3               | Lower Pole Piece                 |
| 112L     | 265C162 P-11                 | 3               | Lower Pole Piece                 |
| 112R     | 265C162 P-14                 | 3               | Lower Pole Piece                 |
| 113L     | 265C162 P-12                 | 3               | Lower Pole Piece                 |
| 113R     | 265C162 P-15                 | 3               | Lower Pole Piece                 |
| 120      | 258C615 P-29                 | 18              | Core                             |
| 121      | 258C616 P-18                 | 18              | Core Insulating Tube             |
| 122      | 6445050 P-10                 | 3               | Spacer                           |
| 123      | 258C615 P-11                 | 3               | Spacer                           |
| 124      | 456A899 P-1                  | 3               | Gasket                           |
| 125      | 414A102 P-6                  | 3               | Stud                             |
| 126      | 421A208 P-81                 | 12              | Spacer                           |
| 127      | 412A209 P-82                 | 9               | Spacer                           |
| 128      | 421A208 P-93                 | 24              | Spacer                           |
| 129      | 421A208 P-80                 | 6               | Spacer                           |
| 130      | 421A208 P-87                 | 6               | Spacer                           |
| 131      | 432249                       | 12              | Spacer                           |
| 132      | 6442389 P-3                  | 6               | Spacer                           |
| 133      | 456A888 P-1                  | 6               | Spacer                           |
| 135      | 456A310 P-1                  | 18              | Washer                           |
| 136      | 421A208 P-78                 | 12              | Spacer                           |
| 137      | 421A208 P-497                | 6               | Spacer                           |
| 138      | 265C150 P-15                 | 6               | Spacer                           |
| 139      | 265C156 P-5                  | 3               | Block                            |
| 140      | 265C156 P-6                  | 3               | Block                            |
| 141      | △△688C583 G-3                | 6               | Coil Support                     |
| 142      | 265C163 P-2                  | 6               | Barrier                          |
| 143      | 688C583 P-12                 | 6               | (Mycalex) Upper Shield           |
| 144      | 414A196 P-1                  | 6               | Spacer                           |
| 145      | 265C150 P-13                 | 6               | Spacer                           |
| 146      | 414A196 P-2                  | 6               | Spacer                           |
| 147      | 265C161 P-16                 | 3               | Spacer                           |
| 148R     | 619C489 P-4                  | 3               | Lower Coil Support (Right)       |
| 148L     | 619C489 P-3                  | 3               | Lower Coil Support (Left)        |
| 149      | 414A198 P-1                  | 3               | Insulation Seal                  |
| 150      | 258C616 P-11                 | 3               | Spacer                           |
| 151      | 265C150 G-4                  | 3               | Connecting Strap                 |
| 152      | 366A743 G-1                  | 3               | Coil (Upper) (C)                 |
| 153      | 265C155 G-3                  | 6               | Coil (Upper) (A and B)           |
| 154      | 265C155 G-8                  | 3               | Coil (Lower) (D)                 |
| 155      | 265C155 G-6                  | 6               | Coil (Lower) (E and F)           |
| 156      | 414A116 P-2                  | 3               | Insulation                       |
| 157      | 414A197 P-1                  | 3               | Shim                             |
| 158      | 414A197 P-2                  | 3               | Shim                             |
| 159      | 265C154 G-3                  | 3               | Runner Assembly                  |
| 160      | 265C154 G-5                  | 6               | Runner Assembly                  |
| 161      | 265C154 G-1                  | 3               | Runner Assembly                  |
| 162      | 265C154 G-9                  | 3               | Runner Assembly                  |
| 163      | 456A888 P-3                  | 9               | Spacer                           |
| 164      | 421A208 P-22                 | 12              | Spacer                           |
| 165      | 6176109 P-18                 | 24              | Spacer                           |
| 166      | 6176109 P-6                  | 24              | Spacer                           |
| 167      | △ 456A336 P-1                | 6               | (Mycalex) Lower Shield           |
| 168      | 456A891 P-210                | 3               | Sleeve                           |
| 169      | △△688C583 G-1                | 3               | Runner Assembly and Coil Support |
| 170      | 265C161 P-17                 | 3               | Spacer                           |
| 171      | 414A131 P-4                  | As required     | Spacer                           |
| 172 *    | 456A891 P-208                | As required     | Spacer                           |
| 173 *    | 619C400 P-32                 | 6               | Block                            |
| 174      | 421A201 P-1                  | 6               | Mycalex                          |
| 175      | 802B735 P-1                  | 6               | Insulation                       |

\* Not Shown

△ Additional Drilling Necessary per 619C488 P-3

△△Furnish Drawings for Additional Work




Fig. 28A Front View




Fig. 28C Back View




Fig. 28B Component Parts

Fig. 28 Rear Bushing Assembly (Ref. No. 150)

Fig. 28A (802042b)

Fig. 28B (802046)

Fig. 28C (8020430)

## PARTS REFERENCED IN FIGS. 28A, 28B AND 28C

| REF. NO. | MVA.        | AMPS. | CAT. NO. FOR AM 13.8(MVA)-3 | NO. REQ. | DESCRIPTION                     |
|----------|-------------|-------|-----------------------------|----------|---------------------------------|
| 150      | *           | 1200  | 236C790 G-6                 | 3        | Rear Bushing Assembly           |
| 150      | 500B, 500AB | 1200  | 236C790 G-7                 | 3        | Rear Bushing Assembly           |
| 150      | ALL         | 2000  | 236C790 G-8                 | 3        | Rear Bushing Assembly           |
| 151      | ALL         | 1200  | 269C841 G-2                 | 3        | Rear Bushing                    |
| 151      | ALL         | 2000  | 265C187 G-5                 | 3        | Rear Bushing                    |
| 152      | *           | 1200  | 6592330 P-2                 | 3        | Spring Retainer                 |
| 152      | 500B, 500AB | 1200  | 6592331 P-2                 | 3        | Spring Retainer                 |
| 152      | ALL         | 2000  | 6592331 P-2                 | 3        | Spring Retainer                 |
| 153      | ALL         | 1200  | 236C791 P-9                 | 3        | Support                         |
| 153      | ALL         | 2000  | 236C791 P-19                | 3        | Support                         |
| 154      | ALL         | ALL   | 236C791 G-3                 | 3        | Arcing Contact Support          |
| 155      | ALL         | ALL   | 236C791 G-1                 | 3        | Flexible Connectors             |
| 155A     | ALL         | ALL   | 236C791 G-4                 | 3        | Flexible Connectors             |
| 156      | ALL         | ALL   | 236C790 G-9                 | 3        | Arcing Contact Assembly         |
| 158      | ALL         | ALL   | 414A116 P-4                 | 3        | Insulating Plate                |
| 159      | ALL         | ALL   | 6445087 P-2                 | 3        | Buffer Clamps (See Ref. 168)    |
| 160      | *           | 1200  | 414A180                     | 12       | Spring                          |
| 160      | 500B, 500AB | 1200  | 6509787 P-1                 | 24       | Spring                          |
| 160      | ALL         | 2000  | 6509787 P-1                 | 24       | Spring                          |
| 161      | *           | 1200  | 236C790 P-22                | 12       | Spring Guide                    |
| 161      | 500B, 500AB | 1200  | 236C790 P-22                | 24       | Spring Guide                    |
| 161      | ALL         | 2000  | 236C790 P-22                | 24       | Spring Guide                    |
| 162      | *           | 1200  | Nar. Wash. 1/4-20           | 12       | Washer For Spring Guide         |
| 162      | 500B, 500AB | 1200  | Nar. Wash. 1/4-20           | 24       | Washer For Spring Guide         |
| 162      | ALL         | 2000  | Nar. Wash. 1/4-20           | 24       | Washer For Spring Guide         |
| 163      | ALL         | ALL   | 175V557 P-1                 | 6        | Lock Plate                      |
| 164      | *           | 1200  | 258C666 P-1                 | 3        | Contact Support                 |
| 164      | 500B, 500AB | 1200  | 258C666 P-3                 | 3        | Contact Support                 |
| 164      | ALL         | 2000  | 258C666 P-2                 | 3        | Contact Support                 |
| 165      | *           | 1200  | 236C791 P-8                 | 12       | Contact Finger                  |
| 165      | 500B, 500AB | 1200  | 236C791 P-8                 | 24       | Contact Finger                  |
| 165      | ALL         | 2000  | 236C791 P-8                 | 24       | Contact Finger                  |
| 166 **   | *           | 1200  | 258C666 P-5                 | 3        | Primary Contact Finger Retainer |
| 166      | 500B, 500AB | 1200  | 236C791 P-20                | 3        | Primary Contact Finger Retainer |
| 166      | ALL         | 2000  | 236C791 P-4                 | 3        | Primary Contact Finger Retainer |
| 166A     | ALL         | 2000  | 236C791 P-3                 | 3        | Primary Contact Finger Retainer |
| 167      | 500B, 500AB | 1200  | 258C666 P-4                 | 3        | Spacer                          |
| 168      | *           | 1200  | 6557243 P-1                 | 6        | Clamp For Buffer                |
| 168      | 500B, 500AB | 1200  | 6557243 P-2                 | 6        | Clamp For Buffer                |
| 168      | ALL         | 2000  | 6557243 P-2                 | 6        | Clamp For Buffer                |
| 169      | ALL         |       | 265C151 P-25                | 3        | Spring Baffle                   |

\* = 150, 250, 500, 150A, 250A, 500A

\*\* Replaced by 258C666 P-16 and 258C666 P-17




Fig. 29A For 2000 Amp. Breakers  
All Ratings

Fig. 29B For 1200 Amp. 500B, 500AB  
MVA Ratings

Fig. 29C For 1200 Amp., 150, 250, 500,  
150A, 250A, 500A MVA Ratings

PARTS REFERENCED IN FIGS. 29A, 29B AND 29C

| REF. NO. | MVA                                 | AMPS. | CAT. NO. FOR AM 13.8 (MVA)-3 | NO. BKR. | DESCRIPTION                  |
|----------|-------------------------------------|-------|------------------------------|----------|------------------------------|
| 210      | (150, 250, 500<br>150A, 250A, 500A) | 1200  | 236C792 G-12                 | 3        | Movable Contact Arm Assembly |
| 210      | 500B, 500AB                         | 1200  | 236C792 G-14                 | 3        | Movable Contact Arm Assembly |
| 210      | ALL                                 | 2000  | 236C792 G-13                 | 3        | Movable Contact Arm Assembly |
| 211      | ALL                                 | ALL   | 802B742 G-3                  | 3        | Movable Arcing Contact       |
| 212      | (150, 250, 500<br>150A, 250A, 500A) | 1200  | 6591644 P-7                  | 3        | Movable Primary Contact      |
| 212      | 500B, 500AB                         | 1200  | 6591644 P-7                  | 6        | Movable Primary Contact      |
| 212      | ALL                                 | 2000  | 6591644 P-7                  | 6        | Movable Primary Contact      |
| 213      | (150, 250, 500<br>150A, 250A, 500A) | 1200  | 6591644 P-8                  | 3        | Movable Primary Contact      |
| 213      | 500B, 500AB                         | 1200  | 6591644 P-8                  | 6        | Movable Primary Contact      |
| 213      | ALL                                 | 2000  | 6591644 P-8                  | 6        | Movable Primary Contact      |
| 214      | ALL                                 | ALL   | 258C666 P-7                  | 6        | Contact Arm                  |
| 215      | 500B, 500AB                         | 1200  | 236C792 G-15                 | 3        | Tube & Piston Assembly       |
| 215      | (150, 250, 500<br>150A, 250A, 500A) | 1200  | 236C792 G-31                 | 3        | Tube & Piston Assembly       |
| 215      | ALL                                 | 2000  | 236C792 G-15                 | 3        | Tube & Piston Assembly       |
| 216      | ALL                                 | 2000  | 258C666 P-6                  | 6        | Contact Arm                  |
| 217      | ALL                                 | ALL   | 421A248 P-1                  | 3        | Piston Ring                  |
| 218      | ALL                                 | ALL   | 456A874 P-3                  | 3        | Piston Ring Expander         |
| 218A     | (150, 250, 500<br>150A, 250A, 500A) | 1200  | 456A874 P-2                  | 3        | Piston Ring Equalizer        |
| 218A     | 500B, 500AB                         | 1200  | 456A874 P-2                  | 6        | Piston Ring Equalizer        |
| 218A     | ALL                                 | 2000  | 456A874 P-2                  | 6        | Piston Ring Equalizer        |
| 219      | ALL                                 | ALL   | 414A146 P-4                  | 12       | Flex Nut                     |
| 220      | ALL                                 | ALL   | 414A146 P-3                  | 6        | Flex Nut                     |
| 221      | 500B, 500AB                         | 1200  | 258C619 P-2                  | 6        | Spacer                       |

Figs. 29A, 29B, 29C (8020383)



Fig. 30A (236C731)




Fig. 30A Early Design




Fig. 30B Present Design

Figs. 30B & 30C (236C787)




Fig. 30C Present Design

Fig. 30 Interlock Plunger

PARTS REFERENCED IN FIGS. 30A, 30B AND 30C FOR ALL RATINGS

| REF. NO. | CATALOG NO. FOR TYPE     |                             | NO. PER MECHANISM | DESCRIPTION                 |
|----------|--------------------------|-----------------------------|-------------------|-----------------------------|
|          | AM-13.8-(MVA)-3 $\Delta$ | AM-13.8-(MVA)-3 $\emptyset$ |                   |                             |
| 324      | 236C769 G-1              | 236C787 G-1                 | 1                 | Plunger interlock, complete |
| 325      | 6442255 P-1              | 236C787 P-12                | 1                 | Plunger for interlock       |
| 326      | 236C769 G-2              | 236C787 G-2                 | 1                 | Bracket for interlock       |
| 327      | 6509728 P-1              | 6509728 P-1                 | 1                 | Spring for interlock        |
| 328      | 6477427 AA P-9           | 137A6085 P-22               | 2                 | Pin                         |
| 329      | 6443714                  | 236C787 P-14                | 1                 | Roller                      |
| 330      | 6477427 CA P-4           | 236C787 P-5                 | 1                 | Pin                         |
| 331      | 6597228 P-1              | 236C787 P-16                | 2                 | Crank                       |
| 332      | 236C769 P-9              | 236C787 P-6                 | 1                 | Front Guard                 |

$\Delta$  This plunger interlock frame is wider than the mechanism frame.

$\emptyset$  This plunger interlock frame is more narrow than the mechanism frame.




Fig. 31A Cross-section







Fig. 31B Complete Spring Assembly (Ref. 273)




VIEW A




VIEW D




VIEW B




VIEW E



VIEW G



VIEW C



VIEW F

Fig. 31C Detailed Views

Fig. 31 MS-13 Mechanism for AM-13.8-3

Fig. 31A (2586688)

Fig. 31B (2586688)

Fig. 31C (2150470)

## PARTS REFERENCED IN FIGS. 31A, 31B, &amp; 31C

| REF. NO. | CAT. NO. FOR AM 13.8 (MVA)-3 | NO. PER MECHANISM | DESCRIPTION   |
|----------|------------------------------|-------------------|---|
| 250      | 6443518 P-1                  | 1                 | Shaft   |
| 251      | 836C190 P-1                  | 6                 | Crank (Std.)  |
| 251      | 836C190 P-2                  | 6                 | Crank (Interchangeable)   |
| 252      | 258C608 P-7                  | 1                 | Latch   |
| 253      | 215D470 G-54                 | 2                 | Crank   |
| 254      | 215D470 G-55                 | 1                 | Link  |
| 255      | 6551742                      | 1                 | Spring  |
| 256      | 258C604 P-8                  | 1                 | Spring Clip   |
| 257      | 6192382 AB P-1               | 1                 | Veeder Counter  |
| 258      | 215D470 G-51                 | 1                 | Link  |
| 259      | 281B711 G-1                  | 1                 | Indicator Assembly  |
| 260      | 258C609 P-1                  | 1                 | Prop  |
| 261      | 6375521 G-2                  | 1                 | Closing Coil 125 v d-c or 230 v a-c 500 MVA                       |
| 261      | 6375521 G-6                  | 1                 | Closing Coil 125 v d-c or 230 v a-c 150 & 250 MVA                 |
| 261      | 6375521 G-1                  | 1                 | Closing Coil (250 v d-c) 500 MVA                                  |
| 261      | 6375521 G-5                  | 1                 | Closing Coil (250 v d-c) 150 & 250 MVA                            |
| 261      | 6375521 G-3                  | 1                 | Closing Coil (220 v a-c) 500B MVA                                 |
| 261      | 6375521 G-4                  | 1                 | Closing Coil (110 v a-c) 500B MVA                                 |
| 262      | 236C796 P-6                  | 1                 | Plunger   |
| 263      | 6591632 P-1                  | 2                 | Piston Ring AM 13.8-150A, 500B, 500AB<br>250A, 500, 500A          |
| 263      | 6591632 P-1                  | 1                 | Piston Ring AM 13.8-150, 250                                      |
| 263A     | 6591632 P-2                  | 1                 | Piston Ring AM 13.8-150, 250                                      |
| 264      | 236C795 P-4                  | 1                 | Pole Piece AM 13.8-150A, 500B, 500AB<br>250A, 500, 500A           |
| 264      | 236C795 P-45                 | 1                 | Pole Piece AM 13.8-150, 250                                       |
| 264A     | 236C796 P-12                 | 1                 | Guide for Pole Piece AM 13.8-150A, 500B, 500AB<br>250A, 500, 500A |
| 264A     | 236C796 P-14                 | 1                 | Guide for Pole Piece AM 13.8-150, 250                             |
| 265      | 414A109 P-4                  | 1                 | Washer  |
| 266      | 236C796 G-2                  | 1                 | Arm Plate   |
| 267      | 236C796 P-8                  | 2                 | Stud  |
| 268      | 383A926 AE P-1               | 1                 | Pin   |
| 269      | 258C630 P-7                  | 1                 | Clevis  |
| 270      | 258C630 P-31                 | 1                 | Plate   |
| 271      | 258C630 P-8                  | 1                 | Rod   |
| 272      | 414A109 P-8                  | 1                 | Buffer  |
| 273      | 258C630 G-1                  | 1                 | Complete Spring Assembly  |
| 274      | 456A808                      | 1                 | Inner Spring  |
| 275      | 456A807                      | 1                 | Outer Spring  |
| 276      | 258C630 P-3                  | 1                 | Spring Retainer   |
| 277      | 258C630 P-5                  | 1                 | Retaining Plate   |
| 278      | 258C630 P-4                  | 1                 | Spring Base   |
| 279      | 383A926 AF P-20              | 1                 | Pin   |
| 280      | 258C630 P-9                  | 1                 | Bracket   |
| 281      | 258C611 P-1                  | 1                 | Trip Shaft (Standard)   |
| 281A     | 258C611 P-2                  | 1                 | Trip Shaft (Interchangeable)                                      |
| 282      | 258C611 P-11                 | 1                 | Stop Bar  |
| 283      | 121A7436 G-1                 | 2                 | Trip Shaft Bearing  |
| 284      | 421A256 P-1                  | 1                 | Spring  |
| 285      | 258C609 P-4                  | 1                 | Crank   |
| 286      | 215D470 G-53                 | 1                 | Roller  |
| 287      | 215D470 G-52                 | 2                 | Link  |
| 288      | 258C611 P-3                  | 1                 | Prop Pin  |
| 289      | 414A110 P-1                  | 1                 | Pin   |
| 290      | 414A112 P-1                  | 1                 | Trip Roller Bearing   |
| 291      | 456A876 P-103                | 2                 | Spacer  |
| 292      | 6509799                      | 2                 | Spring  |
| 293      | 414A110 P-3                  | 1                 | Pin   |
| 294      | 6477097                      | 1                 | Prop Spring   |
| 295      | 258C609 P-8                  | 1                 | Trip Roller Pin   |
| 296      | 104A2474 P-1                 | 1                 | Pin   |
| 299      | 421A210 P-1                  | 2                 | Spacer  |
| 301      | 258C608 P-3                  | 1                 | Latch Guide   |
| 302      | 258C611 P-5                  | 1                 | Pin   |
| 303      | 258C609 P-9                  | 1                 | Pin   |
| 304      | 421A209 P-101                | 2                 | Spacer  |
| 305      | 258C609 P-6                  | 1                 | Roller  |
| 306      | 383A926AE P-39               | 1                 | Pin   |
| 307      | 421A208 P-143                | 2                 | Spacer  |
| 308      | 688C568 P-8                  | 1                 | Pin (Center Pole)   |
| 308      | 619C478 P-19                 | 2                 | Pin (End Poles)   |
| 309      | 6442239                      | 2                 | Bearing   |




Fig. 32A Right Side View

Fig. 32B Front View

Fig. 32C Left Side View

Fig. 32 MS-13 Mechanism for Type AM 13.8-3 Breaker

PARTS REFERENCED IN FIGS. 32A, 32B AND 32C FOR ALL RATINGS

| REF. NO. | CAT. NO. TYPE<br>AM 13.8 (MVA)-3 | NO. PER<br>MECHANISM | DESCRIPTION                     |
|----------|----------------------------------|----------------------|---------------------------------|
| 350      | 258C604 G-3                      | 1                    | Manual Trip Rod                 |
| 351      | 258C604 P-2                      | 1                    | Manual Trip Rod Support         |
| 352      | 236C795 P-40                     | 1                    | Rod                             |
| 353      | 174V394 P-1                      | 1                    | Tube                            |
| 354      | 6445059                          | 1                    | Insulating Tube                 |
| 356      | 415A489 G-1                      | 1                    | Auxiliary Switch                |
| 358      | 456A876 P-4                      | 2                    | Spacer                          |
| 359      | 236C788 P-6                      | 1                    | Interlock Prop Shaft            |
| 360      | 104A2476                         | 1                    | Spring                          |
| 361      | 236C788 P-3                      | 1                    | Interlock Prop                  |
| 362      | 258C601 G-3                      | 1                    | Bearing Bracket                 |
| 363      | 258C601 P-15                     | 1                    | Shaft                           |
| 364      | 236C788 P-8                      | 2                    | Link                            |
| 365      | 236C788 P-7                      | 1                    | Crank                           |
| 366      | 258C601 P-16                     | 1                    | Crank                           |
| 367      | 236C788 P-30                     | 1                    | Bracket                         |
| 368      | 456A866 P-1                      | 1                    | Latch Checking Switch           |
| 369      | 456A866 P-1                      | 1                    | Interlock Switch                |
| 370      | 6174582 G-1                      | 1                    | Potential Trip Coil (125 v d-c) |
| 370      | 6174582 G-2                      | 1                    | Potential Trip Coil (250 v d-c) |
| 370      | 6174582 G-14                     | 1                    | Potential Trip Coil (230 v a-c) |
| 370      | 6275070 G-1                      | 1                    | Potential Trip Coil ( 24 v d-c) |
| 370      | 6275070 G-2                      | 1                    | Potential Trip Coil ( 48 v d-c) |
| 371      | 215D470 G-5                      | 1                    | Potential Trip Linkage          |

Fig. 33 (8026055)




Fig. 34 (8022396)




Fig. 33 Secondary Disconnecting Device  
Ref. No. 500

Fig. 34 Maintenance Closing Device  
Ref. No. 510

PARTS REFERENCED IN FIGS. 33 & 34 FOR ALL RATINGS

| REF. NO. | CAT. NO. FOR TYPE AM 13.8 (MVA)-3 | NO. PER MECHANISM | DESCRIPTION                                     |
|----------|-----------------------------------|-------------------|---|
| 500      | 802B795 G-3                       | 1                 | Secondary Disconnect Device, Complete: 16 point |
| 500      | 264B173 G-1                       | 1                 | Secondary Disconnect Device, Complete: 7 point  |
| 503      | 6319964 P-2                       | 16                | Plug  |
| 505      | 848768 P-1                        | 16                | Lock Washer for Plug                            |
| 507      | 6505244 P-1                       | 1                 | Socket  |
| 510      | 258C669 G-1                       | 1                 | Maintenance Closing Device                      |
| 511      | X-3663094 P-38                    | 3                 | Spacer  |
| 512      | 366A234 P-1                       | 2                 | Contact Nut                                     |
| 512      | 366A234 P-2                       | 14                | Contact Nut                                     |




Fig. 35 Partial View of MS-13 Mechanism with Current Trip




Fig. 36 Undervoltage Device (Ref. 647)

PARTS REFERENCED IN FIGS. 35 AND 36 FOR ALL RATINGS

| REF. NO. | CAT. NO. FOR TYPE | NO. PER MECHANISM | DESCRIPTION                        |
|----------|-------------------|-------------------|------------------------------------|
|          | AM-13.8-(MVA)-3   |                   |                                    |
| 600      | 6551725           | 1                 | Spring                             |
| 601      | 366A611 G-1       | 1                 | Trip Pan                           |
| 602      | 6558748 P-1       | 1                 | Bracket                            |
| 603      | 6558756 P-1       | 1                 | Trip Latch                         |
| 604      | 6477418 AA P-10   | 1                 | Ball Bearing                       |
| 605      | 366A600 P-1       | 1                 | Trip Arm                           |
| 606      | 6076401 P-307     | 1                 | Pin                                |
| 607      | 6477427 AA P-8    | 1                 | Pin                                |
| 647      | 213X0185 G-001    | 1                 | A.C. Undervoltage Device less coil |
| 647      | 213X0217 G-001    | 1                 | D.C. Undervoltage Device less coil |
| 648      | 175V574           | 1                 | Stop for d-c only                  |
| 649      | 369A443           | 1                 | Spring for d-c only                |
| 650      | 6551726           | 1                 | Spring for a-c only                |
| 651      | 175V578           | 1                 | Pin for d-c only                   |
| 652      | 6076401 P-309     | 1                 | Pin for a-c only                   |
| 653      | 6076401 P-305     | 2                 | Pin                                |
| 654      | 295B227 G-2       | 1                 | Switch                             |
| 655      | 175V576           | 1                 | Pin                                |
| 656      | 374A246 P-1       | 1                 | Bracket                            |
| 657      | 175V562 P-1       | 1                 | Shim for d-c only                  |
| 658      | 384A330 G-1       | 1                 | Link Arm Assembly for d-c only     |
| 659      | 6477414 AC P-20   | 1                 | Stud                               |
| 660      | 6558711 P-1       | 2                 | Coupling                           |
| 661      | 6558723 G-1       | 1                 | Trip Arm                           |
| 662      | 6509798           | 2                 | Spring                             |
| 663      | 6275017 G-19      | 1                 | Coil (125 v d-c)                   |
| 663      | 6275017 G-33      | 1                 | Coil (230 v a-c)                   |
| 663      | 6275017 G-20      | 1                 | Coil (250 v d-c)                   |

Fig. 35 (8020216)

Fig. 36 (8016105)




Fig. 37 Impact Trip Device (Ref. 702)

PARTS REFERENCED IN FIG. 37 FOR ALL RATINGS

| REF. NO. | CAT. NO. FOR TYPE AM-13.8-(MVA)-3 | NO. PER MECHANISM | DESCRIPTION                       |
|----------|-----------------------------------|-------------------|-----------------------------------|
| 702      | 6594553 AA                        | 1                 | Impact Trip Device Complete       |
| 703      | 6591817 P-1                       | 1                 | Lever                             |
| 704      | 6591388 P-19                      | 1                 | Locking Plate                     |
| 705      | 6076403 P-315                     | 1                 | Pin                               |
| 706      | 6477425 BA P-3                    | 1                 | Roller                            |
| 709      | 6076403 P-311                     | 1                 | Pin                               |
| 710      | 6592554 G-1                       | 1                 | Crank                             |
| 711      | 6557106 P-1                       | 1                 | Adjusting Screw                   |
| 713      | 6558791 G-1                       | 1                 | Eyebolt Assembly                  |
| 715      | 6509706                           | 1                 | Spring                            |
| 716      | 6443516                           | 1                 | Bracket                           |
| 717      | 6557105 P-1                       | 1                 | Spacer                            |
| 718      | 6558746 P-1                       | 1                 | Bracket                           |
| 719      | 6558747 P-1                       | 1                 | Trip Arm                          |
| 720      | 6076401 P-315                     | 1                 | Pin                               |
| 721      | 6477401 AA P-3                    | 2                 | Spacer                            |
| 722      | 6509794                           | 1                 | Spring                            |
| 723      | 174V378                           | 1                 | Rod                               |
| 725      | 174V373                           | 1                 | Coupling                          |
| 726      | 6443666                           | 1                 | Bracket                           |
| 727      | 295B227 G-3                       | 1                 | Switch                            |
| 728      | 6592505 AA                        | 1                 | Frame Assembly                    |
| 729      | 6558752 G-1                       | 1                 | Core Assembly                     |
| 730      | 6558751 P-1                       | 1                 | Angle                             |
| 731      | 6049320                           | 3                 | Felt Washer                       |
| 732      | 6557068 P-9                       | 1                 | Pin                               |
| 734      | 6076401 P-385                     | 1                 | Pin                               |
| 735      | 2236575                           | 2                 | Guide                             |
| 736      | 4905058 G-4                       | 1                 | Coil Frame                        |
| 737      | 6443667                           | 1                 | Bracket                           |
| 738      | 6174599 G-2                       | 3                 | Coil for Current Trip 3 Amp a-c   |
| 738      | 6174599 G-6                       | 1                 | Coil for Capacitor Trip 230 v a-c |
| * 739    | 456A334 P-1                       | 1                 | Rubber Guard                      |

\* Not Shown

Fig. 37 (8016104)




Fig. 38 Control Device for all Mechanisms (Ref. 750)

PARTS REFERENCED IN FIG. 38 FOR ALL RATINGS

| REF. NO. | CAT. NO. FOR TYPE | NO. PER MECHANISM | DESCRIPTION                                |
|----------|-------------------|-------------------|--|
|          | AM 13.8 (MVA)-3   |                   |  |
| 750      | 403A225 G-1       | 1                 | Control Device, 125 Volt, d-c              |
| 750      | 403A224 G-4       | 1                 | Control Device, 230 Volt, a-c (continuous) |
| 750      | 6375988 G-6       | 1                 | Control Device, 250 Volt, d-c              |
| 750      | 403A224 G-3       | 1                 | Control Device, 230 Volt, a-c              |
| 751      | 295B227 G-2       | 1                 | Auxiliary Switch, top or back              |
| 752      | 295B227 G-1       | 1                 | Auxiliary Switch, top, 230 Volt, a-c only  |
| 753      | 6275017 G-19      | 1                 | Coil, 125 Volt, d-c                        |
| 753      | 6275017 G-33      | 1                 | Coil, 230 Volt, a-c (continuous)           |
| 753      | 6275017 G-20      | 1                 | Coil, 250 Volt, d-c                        |
| 753      | 6275017 G-34      | 1                 | Coil, 230 Volt, a-c (intermittent)         |
| 754      | 6591455 P-1       | 2                 | Support for Contact Tip                    |
| 755      | 6442392 P-1       | 2                 | Insulation                                 |
| 756      | 6591411 G-1       | 2                 | Support for Stationary Contact             |
| 757      | 6591450 P-1       | 2                 | Core                                       |
| 758      | 6412255 P-1       | 2                 | Blowout Coil                               |
| 759      | 6412251 P-1       | 2                 | Support for Coil                           |
| 760      | 6591440 G-1       | 1                 | Connector                                  |
| 761      | 6592161 P-1       | 2                 | Support for Movable Contact                |
| 762      | 6592162 P-1       | 2                 | Shield                                     |
| 763      | 6477041 P-1       | 2                 | Spring                                     |
| 764      | 6591412 G-1       | 2                 | Movable Contact                            |
| 765      | 6591404 G-1       | 2                 | Arc Chute Assembly                         |
| 766      | 6272844           | 1                 | Spring                                     |
| 767      | 365A458           | 1                 | Spring (a-c Int. & d-c)                    |
| 767      | 6370699           | 1                 | Spring (a-c Cont.)                         |
| 768      | 6477063           | 1                 | Spring                                     |
| *769     | 456A812 G-1       | 1                 | Hardware for Mounting Control Device       |

\* Not Shown

Fig. 38 (8011083)